



TRIUMPH

We strive to ensure that our products are of the highest quality and free of manufacturing defects or missing parts. However, if you have any problems with your new product,

DO NOT RETURN IT TO THE STORE,

please contact us toll free @:

1-888-996-2729

FAX: 1-866-873-3535

gameroom@escaladesports.com

Or write to:

Escalade Sports
Customer Service Department
P.O. Box 889
Evansville IN 47706

Please visit our Web site at:

www.escaladesports.com

Please have your model number when inquiring about parts.

When contacting Escalade Sports please provide your model number, date code (if applicable), and part number if requesting a replacement part. These numbers are located on the product, packaging, and in this owners manual.


Your Model Number: **45-6736W/F**

Date Code: **2-45-6736F- -HL**

Purchase Date: _____

PLEASE RETAIN THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE

**IMPORTANT! READ EACH STEP
IN THIS MANUAL BEFORE YOU
BEGIN THE ASSEMBLY.**



TWO ADULTS ARE REQUIRED TO ASSEMBLE THIS 4-IN-1 AIRZONE SWIVEL TABLE

**SOCCER, BILLIARDS, AIR HOCKEY, TABLE TENNIS
PLUS BONUS AIRZONE SOCCER GAME**

Tools Required:

Allen Wrench (Included)
Phillips Screwdriver
Furniture Polish and Cloth

An electric screwdriver is helpful in assembly. However, please set at low torque and use extreme caution with an electric screwdriver because you could overtighten the hardware and strip the screws.

Assembly Tips

Make sure you understand the following tips before you begin to assemble your hockey table.

1. Start all bolts by hand before tightening.
2. Some drawings or images in this manual may not look exactly like your product. Please read and understand the text before starting each assembly step.



WARNING:

**READ AND FOLLOW ALL ASSEMBLY, OPERATION, AND
SAFETY INSTRUCTIONS CAREFULLY. AT LEAST TWO
ADULTS ARE NEEDED TO ASSEMBLE THIS GAME TABLE**

HARDWARE IDENTIFIER

(To Scale)




H1 = 8 pcs
4 mm x 22 mm
Phillips Head Bolt




H2 = 8 pcs
4.5 mm x 10 mm
Flat Washer



H3 = 8 pcs
M4 STD Nut




H4 = 8 pcs
6 mm x 40 mm
Allen Head Bolt




H5 = 24 pcs
6.5 mm x 16 mm
Flat Washer




H6 = 26 pcs
4 mm x 40 mm
Phillips Round
Head Screw



H7 = 16 pcs
6 mm x 25 mm
Allen Head Bolt




H8 = 12 pcs
3.5 mm x 14 mm
Phillips Round
Head Screw



H9 = 12 pcs
3.5 mm x 35 mm
Phillips Flat
Head Screw



H10 = 4 pcs
3.5 mm x 25 mm
Phillips Flat
Head Screw




(Not to Scale)

H11 = 2 pcs
Plastic Pivot Bolt




H12 = 16 pcs
3.5 mm x 28 mm
Phillips Round
Head Screw




(Not to Scale)

T1 = 1 pc
Allen Wrench

PARTS IDENTIFIER (Not to Scale)



P1 - Main Cabinet
(1 pc)




P2 - Leg Top
End Apron
(2 pcs)




P3 -Right Leg
(2 pcs)




P4 - Left Leg
(2 pcs)




P5 - Side Leg Panel
(2 pcs)




P6 - End Leg Panel
(2 pcs)




P7 - Center Frame Support
(2 pcs)




P8 - Top Side End Panel
(2 pcs)



P9 - Ball Storage
Board-Lower
(2 pcs)




P10 - Goal Box
(2 pcs)




P11 - Table Tennis
Board
(1 pc)




P12 - Leg Leveler
(4 pcs)




P13 - Manual Scorer
(2 pcs)




P14 - White 3-player
Rod Assembly
with rod handle, plastic washers,
rod end caps and bumpers attached
(2 pcs)




P15 - White 5-player
Rod Assembly
with rod handle, plastic washers,
rod end caps and bumpers attached
(1 pc)




P16 - White 2-player
Rod Assembly
with rod handle, plastic washers,
rod end caps and bumpers attached
(1 pc)




P17 - Red 3-player
Rod Assembly
with rod handle, plastic washers,
rod end caps and bumpers attached
(2 pcs)



P18 - Red 5-player
Rod Assembly
with rod handle, plastic washers,
rod end caps and bumpers attached
(1 pc)



P19 - Red 2-player
Rod Assembly
with rod handle, plastic washers,
rod end caps and bumpers attached
(1 pc)



P20 - Lock Latch
(4 pcs)



P21 - Billiard Playfield
(1 pc)



P22 - Corner Pocket
Shield (4 pcs)



P23 - Side Pocket
Shield (2 pcs)



P24- Removable Bushing
Cap with Push Lock
(8 pcs)



A2 - Table Tennis Paddle
(2 pcs)



A3 - Table Tennis Ball
(2 pcs)




A4- Table Tennis Net Post
(2 pcs)




A5 - Cue Stick
(2 pcs)




A6 - Billiards Playfield Brush
(1 pc)



A7 - Triangle
(1 pc)



A8- Cue Tip Chalk
(1 pc)




A9 - Billiard Balls
(1 set)




A10 - Cue Holder
(2 pcs)




A11 - Soccer Ball
(2 pcs)




A12- Table Tennis Net
(1 pc)



A13- Air Soccer Puck
(1 pc)



A14 - A/C Adapter
(1 pc)



A15 - Hockey Pusher
with felt pad attached
(2 pcs)



A16 - Hockey Puck
(2 pcs)

PARTS REQUIRED:

1 pc - **P1** Main Cabinet

2 pcs - **H11** Plastic Pivot Bolt

1 pc - **P21** Billiard Playfield

Step 1

Please inspect the main cabinet and playing surfaces before putting the game together.

Remove all the contents from inside the carton and verify that you have all listed parts as shown on the parts list.

NOTE: Parts are packed inside and under the table cabinet. Remove the billiards playfield **P21** from Main Cabinet. Inside the table cabinet you will find parts needed to assemble your table.

Attach the Plastic Pivot Bolts **H11** to the Plastic Pivot Nuts **C5** to each end of Main Cabinet.

Hand tighten the Plastic Pivot Bolts **H11**.




FIGURE 1

PARTS REQUIRED:

12 pcs - **H8** 3.5 x 14mm Phillips Round Head Screw
16 pcs - **H12** 3.5 x 28mm Phillips Round Head Screw


4 pcs - **P22** Corner Pocket Shield
2 pcs - **P23** Side Pocket Shield

Step 2 Before Starting Step 2, Double Check That All Loose Table Components and Packing Materials Are Removed From The Main Table Cabinet.

When all the parts are out of the Main Table Cabinet **P1**, replace the Billiards Playfield **P21**.

Attach the Billiards Playfield **P21** by using screws **H12**.

Tighten, but do not strip out Screws H12




Step 3

Insert Corner Pockets Shields **P22** and Side Pocket Shields **P23** into the the cabinet pockets using Screws **H8**.

Tighten, but do not strip out Screws H8

NOTE: Carefully pull and hold each Pocket Shield tight into the pocket for correct screw installation.




PARTS REQUIRED:

2 pcs - P2 Leg Top End Apron	2 pcs - P3 Right Leg	2 pcs - P4 Left Leg	4 pcs - P20 Lock / Latch
8 pcs - H1 4 x 22mm Phillips Head Bolt	8 pcs - H2 4.5 x 10mm Flat Washer		
8 pcs - H4 6 x 40mm Allen Head Bolt	8 pcs - H5 6.5 x 16mm Flat Washer		8 pcs - H3 M4 STD Nut


Step 4 (Build 2 Identical Assemblies)

Attach 2 pieces Lock / Latches **P20** into the cut outs on Leg Top End Apron **P2** with Bolts **H1**, Washers **H2** and Nuts **H3**, then tighten, but DO NOT over tighten.



Step 5 (Build 2 Identical Assemblies)

Attach the Right leg **P3** and Left Leg **P4** to the Leg Top End Apron **P2** by inserting Bolts **H4** with washers **H5** into the predrilled holes of the leg and into the Barrel Nuts, then tighten, but DO NOT over tighten.



PARTS REQUIRED:

2 pcs - **P9** Ball Storage Board-Lower

2 pcs - **P10** Goal Box

4 pcs - **P12** Leg Leveler

18 pcs - **H6** 4 x 40mm Phillips Round Head Screw


Step 6 (Build 2 Identical Assemblies)

Screw the Ball Storage Board-Lower **P9** to the Leg Top End Apron **P2** using screws **H6** into predrilled holes.

Install leg levelers **P12** to the bottom of each Leg **P3** & **P4**.

Tighten, but do not strip out screws **H6**.

Note: Be careful to orientate parts exactly the same as the assembly diagrams.




Step 7 (Build 2 Identical Assemblies)

Attach the Goal Box **P10** to the Leg Top End Apron **P2** with screws **H6** using the predrilled holes.

Tighten, but do not strip out screws **H6**.

Note: Align all 4 holes to install H6 Screws



PARTS REQUIRED:

2 pcs - **P5** Side Leg Panel

2 pcs - **P7** Center Frame Support

8 pcs - **H6** 4 x 40mm Phillips Round Head Screw

2 pcs - **P6** End Leg Panel


16 pcs - **H5** 6.5 x 16mm Flat Washer

16 pcs - **H7** 6 x 25mm Allen Head Bolt

Step 8

With the help of another adult, attach the Side Leg Aprons **P5** and End Leg Aprons **P6** to the assembled leg pedestals by aligning the holes in the corner braces on the leg pedestal with the predrilled holes in the Leg Aprons **P5 & P6** using bolts **H7** and washers **H5**.

Tighten all **H7** Bolts using the Allen wrench **T1** at this time.



Note: The steel heads of the pre-installed T-Nuts in the P6 End Aprons must go to the inside for correct assembly.

Step 9

Attach the Center Frame Supports **P7** to the Side Leg Apron **P5** using predrilled holes with Screws **H6**

Tighten, but do not strip out screws **H6**.




FIGURE 9

Step 10

Install the Main Cabinet **P1** by sliding the Plastic Pivot Bolts **H11** into the 2 slots on each Leg Top End Apron **P2**. Make sure the plastic pivot bolts **H11** rests in the slots on each end of the Leg Top End Apron **P2**.




FIGURE 10

PARTS REQUIRED:

2 pcs - **P8** Top Side End Panel

2 pcs - **P13** Manual Scorer

1 pc - **A14** A/C Adapter

12 pcs - **H9** 3.5 x 35 mm Phillips Flat Head Screw

4 pcs - **H10** 3.5 x 25 mm Phillips Flat Head Screw

Step 11

Attach Top Side End Panels **P8** to the assembled leg pedestals by aligning the holes in the Top Side End Panels **P8** with the predrilled holes in the top of the Leg Top End Apron **P2**, and attach with screws **H9**.

Tighten, but do not strip out screws H9.




FIGURE 11

Step 12

Attach Manual Scorers **P13** to the Top Side End Panels **P8** using screws **H10**.
Tighten, but do not strip out screws H10.

Note: Always disconnect the **A14 A/C Adapter** from the wall outlet and main cabinet when play is completed or when not in use.




FIGURE 12

PARTS REQUIRED:

2 pcs - **P14** White 3-player Rod Assembly 1 pc - **P15** White 5-player Rod Assembly 1 pc - **P16** White 2-player Rod Assembly
 2 pcs - **P17** Red 3-player Rod Assembly 1 pc - **P18** Red 5-player Rod Assembly 1 pc - **P19** Red 2-player Rod Assembly
 8 pcs - **P24** Removable Bushing Cap with Pusk Lock

Step 13 **NOTE: STUDY DIAGRAM CLOSELY FOR CORRECT PLAYER ROD PLACEMENT.**





FIRST: Insert the Rod into the round bushing hole as shown in **FIGURE 13A**.

Second: Snap the Removable Bushing Cap **P24** into the female bushing as shown in **FIGURE 13B**



When you finish playing the Soccer Game, and wish to play Billiards or Table Tennis, push the Lock of the Removable Bushing Cap **P24** and remove the Removable Bushing Cap.

Slide back the rod from the round bushing hole as shown in **FIGURE 13C** and **13D**.

NOTE: There will be four handles on each side of the table. It is critical that you set the player rods as shown below so the players will be correctly placed.



Must "Lock" into
female bushing



Upright / Top View

PARTS REQUIRED:

1 pc - **A12** Table Tennis Net

2 pcs - **A4** Table Tennis Net Post

1 pc - **P11** Table Tennis Board

Step 14 (Rotate Table To Play Billiards)

To swivel table, first - remove all 8 pcs Removable Bushing Caps A16. Second - remove and stow all Player Rods as per Diagram below. Third - replace all 8 pcs Removable Bushing Caps A16. Open or unlock all 4 Lock /Latches. And very carefully swivel the main cabinet.

Close and lock all 4 Lock /Latches to play the Billiards Game.

NOTE: All Soccer Rods must be removed before rotating the table.

Also make sure A/C adapter cord is disconnected from the table.




FIGURE 14

Step 15 (Remove Player Rods, But Do Not Rotate Table To Play Air Hockey or Table Tennis)

Store the soccer player rods on the Center Frame Supports **P7** under the table to play the Air Hockey Game.

Place the Table Tennis Board **P11** onto the Billiard surface and insert the net posts **A4** and net **A12** to play the Table Tennis Game.




FIGURE 15

AIR POWERED HOCKEY:

1. This game is designed to be played with two (2) players, one at each end. Plug in A/C Adapter.
2. Play begins when the puck is placed on the playing surface. Players must hit the puck with the hand-held pushers and attempt to shoot into the opponent's goal.
3. One point is given when a puck is shot into the opponent's goal.
4. Winning: the winning goal is accomplished by being the first player to reach a predetermined score or by being the player to score the most points within a given period. Unplug A/C Adapter when not in use.

SOCCER:

1. This game is intended for 2-4 players. Competing teams will be on opposite sides of the table from one another.
2. Players must use the player rods to maneuver the ball into your opponent's goal to score one point.
3. Spinning the rods with uncontrollable force is not allowed.
4. If a ball comes to a complete stop, a timeout occurs and the ball is dropped into the middle to start play back up again.

Note: Use the ball entry cup for this if provided on your game table

BILLIARDS:

In the course of play, a player must call each shot in advance, by indicating the ball to be made and the pocket into which it will be made. It is not necessary to indicate details such as cushions, banks, caroms, etc. Failure to make the shot as called results in a loss of turn. If the shot is made as called, then any other balls pocketed remain pocketed. However, if the called shot is not made and any other balls are pocketed, then the shooter's ball(s) that were pocketed would be spotted and any of the opponent's balls would remain pocketed.

In order to execute a Legal Shot, the first ball hit must be one of the balls in the shooter's group (stripes or solids) and the object ball must be pocketed or the cue ball or any object ball must come into contact with a rail. (Note: It is legal for the shooter to bank the cue ball off a rail before hitting the object ball.) A player who legally pockets a ball continues play until missing or committing a Foul. Once a player's ball group (stripes or solids) is pocketed, the player may play the 8 ball. Again, the player must clearly indicate the intended pocket, even if it appears obvious. A player who legally pockets all of his ball group and the 8 ball is the winner.

FOULS

1. Failure to execute a legal shot as defined above.
2. A scratch shot (shooting the cue ball into a pocket or off the table)
3. Moving or touching any ball by means other than legal play.
4. Shooting an intentional jump shot over another ball by scooping the cue stick under the cue ball. (A jump shot executed by striking the cue ball above center is legal.)
5. Using the 8 ball first in a combination shot when the table is not open.

TABLE TENNIS:

In singles, the server first makes a good service and then the receiver makes a good return. Thereafter, server and receiver alternately each make a good return. In doubles, the server first makes a good service and the receiver returns the ball. Then the partner of the server makes a good return, followed by the partner of the receiver returning the ball. Thereafter, each player alternately in that sequence makes a good return

BONUS AIRZONE SOCCER GAME:

Your 4 in 1 multi game table includes a new bonus game called "AirZone" Soccer.

A new exciting twist on the games of air hockey and foosball.


Using the included Air soccer puck (A13) you can now play Air rod soccer on the air hockey playfield.

The "AirZone" playfield provides a cushion of air for a new gaming experience. Plug in A/C Adapter.

The game rules are the same as traditional foosball.

Younger novice players may find this version of air soccer a little easier to play than foosball.


Always unplug A/C Adapter when not in use.



Female Bushing Replacement

In the remote chance that the female rod bushing may need to be replaced , please follow these replacement directions.

1. Call our Customer Service Department at 1-888 on the front of your assembly manual and request the bushing replacement.
2. Locate and remove the Philips screw in the bushing , as per the diagram.
3. Pinch the bushing together and pull the bushing up and out of it's slot , per the diagram.
4. Install the new bushing , and replace the screw. Tighten , but do not strip out the screw.



Congratulations! You have now assembled your Swivel Table. Please note the Care and Use instructions below to ensure many years of trouble free use of your Swivel Table.

CARE AND USE OF YOUR SWIVEL TABLE

1. Use only a suitable 120v AC household outlet, and insure the cord is not a trip hazard.
2. For long life and best play from your air hockey table, apply spray furniture polish to clean cloth and wipe down the playfield with air motor running to make the pucks slide faster before first play and frequently thereafter.
3. Use spray furniture polish to clean all exterior surfaces of your 4in1 table.
4. Use the Billiards Playfield brush provided to clean the cloth on the billiards table.
5. Use a carpenters level to properly level table using the leg levelers.
6. This product is intended for **INDOOR** use only.
7. **DO NOT** operate the motor if the cord is damaged in any way.
8. **DO NOT** sit, climb or lean on the table.
9. **DO NOT** drag the table when moving it. This will damage the legs.
10. **DO NOT** set drinks on the table.
11. It is suggested that this table be placed close to wall thus allowing the air motor cord to **NOT** be a trip hazard. Always turn air motor off when table is not in use.
12. If possible, cover table with a pool table cover or sheet when not used to keep playfield clean preventing any dust build up.

PRODUCT PARTS LIST FOR MODEL # 45-6736

Part #	Description	Qty	Part #	Description	Qty
45-6736HLH1	4 x 22 mm Phillips Head Bolt	8	45-6736HLP18	Red 5-Player Rod Assembly	1
45-6736HLH2	4.5 x 10 mm Flat Washer	8	45-6736HLP19	Red 2-Player Rod Assembly	1
45-6736HLH3	M4 Nylock Nut	8	45-6736HLP20	Lock Latch	4
45-6736HLH4	6 x 40 mm Allen Head Bolt	8	45-6736HLP21	Billiard Playfield	1
45-6736HLH5	6.5 x 16 mm Flat Washer	24	45-6736HLP22	Corner Pocket Shield	4
45-6736HLH6	4 x 40 mm Phillips Round Head Screw	26	45-6736HLP23	Side Pocket Shield	2
45-6736HLH7	6 x 25 mm Allen Head Bolt	16	45-6736HLP24	Removable Bushing Cap with Push Lock	8
45-6736HLH8	3.5 x 14 mm Phillips Round Head Screw	12	45-6736HLA17	Table Tennis Paddle	2
45-6736HLH9	3.5 x 35 mm Phillips Flat Head Screw	12	45-6736HLA3	Table Tennis Ball	2
45-6736HLH10	3.5 x 25 mm Phillips Flat Head Screw	4	45-6736HLA18	Table Tennis Net Post	2
45-6736HLH11	Plastic Pivot Bolt	2	45-6736HLA5	Cue Stick	2
45-6736HLH12	3.5 x 28 mm Phillips Round Head Screw	16	45-6736HLA6	Billiards Playfield Brush	1
45-6736HLT1	Allen Wrench	1	45-6736HLA7	Triangle	1
45-6736HLP1	Main Cabinet	1	45-6736HLA8	Cue Tip Chalk	2
45-6736HLP2	Leg Top End Apron	2	45-6736HLA9	Billiard Balls	1
45-6736HLP3	Right Leg	2	45-6736HLA10	Cue Holder	2
45-6736HLP4	Left Leg	2	45-6736HLA11	Soccer Ball	2
45-6736HLP5	Side Leg Panel	2	45-6736HLA12	Table Tennis Net	1
45-6736HLP6	End Leg Panel	2	45-6736HLA13	Air Soccer Puck	1
45-6736HLP7	Center Frame Support	2	45-6736HLA14	A/C Adapter	1
45-6736HLP8	Top Side End Panel	2	45-6736HLA15	Pusher	2
45-6736HLP9	Ball Storage Board-Lower	2	45-6736HLA16	Puck	2
45-6736HLP10	Goal Box	2	45-6736HLC1	Rod Washer (Factory Installed)	16
45-6736HLP25	Table Tennis Board	1	45-6736HLC2	Rod Bumper (Factory Installed)	16
45-6736HLP12	Leg Leveler	4	45-6736HLC3	Quick Connect Bushing -Female (Factory Installed)	8
45-6736HLP13	Manual Scorer	2	45-6736HLC4	Rod Handle (Factory Installed)	8
45-6736HLP14	White 3-Player Rod Assembly	2	45-6736HLC5	Plastic Pivot Nut (Factory Installed)	2
45-6736HLP15	White 5-Player Rod Assembly	1	45-6736HLC6	DC Motor with Wire (Factory Installed)	2
45-6736HLP16	White 2-Player Rod Assembly	1	45-6736HLM1	Instruction Manual	1
45-6736HLP17	Red 3-Player Rod Assembly	2	Note: The Soccer Player Rods all have the Players, Washers, Bumpers, Rod Handle and Rod End Cap all pre-attached.		
45-6736HLK1	Hardware Kit	1			

90 DAY LIMITED WARRANTY

This consumer warranty extends to the original consumer purchase of any ESCALADESPORTS Product (hereinafter referred as the "Product").

WARRANTY DURATION: This Product is warranted to the original consumer purchase of a period of 90 days from the original purchase.

WARRANTY COVERAGE: ESCALADE SPORTS warrants to the original Consumer Purchaser that any Product of its manufacture is free from defects in material and workmanship when used for the intended purpose under normal use and conditions. THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN DAMAGED BY ACCIDENT, UNREASONABLE USE, NEGLIGENCE, IMPROPER SERVICE, FAILURE TO FOLLOW INSTRUCTIONS PROVIDED WITH THE PRODUCT OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIAL AND WORKMANSHIP.

WARRANTY PERFORMANCE: During the above 90 day warranty period, ESCALADESPORTS shall repair or replace with a comparable model, and Product, or component thereof, which may prove defective under normal use and proper care, and which our examination shall disclose to our satisfaction to be thus defective, please contact our Warranty Dept.

1-888-996-2729 / Warranty Dept.

Or Write us at:

Escalade® Sports, Inc. - P.O. Box 889, Evansville, IN 47706

Attn: Warranty Dept.

Or E-mail us at:

gameroom@escaladesports.com

Other than shipping requirements no charge will be made for such repair or replacement of in-warranty Products. ESCALADE SPORTS strongly recommends that the Product is insured for value prior to mailing.

WARRANTY DISCLAIMERS: ANY IMPLIED WARRANTIES ARISING OUT OF THIS SALE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE ABOVE 90 DAY PERIOD. ESCALADE SPORTS SHALL NOT BE LIABLE FOR LOSS OF USE OF THE PRODUCT OR OTHER CONSEQUENTIAL OR INCIDENTAL COSTS, EXPENSES OR DAMAGES INCURRED BY THE CONSUMER OF ANY OTHER USE.

Some states do not allow the exclusion or limitation of implied warranties or consequential or incidental damages, so the above limitations or exclusions may not apply to you.

LEGAL REMEDIES: This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.