




Required tools



- A. Glass
- B. Post
- C. Cap
- D. Washer
- E. Anchor
- F. Screw
- G. Tray
- H. Print
- I. Eraser




1

Requires 1 person to carefully hold glass in place, and 1 person to mark holes (4X).




Hang vertically or horizontally to match desired print



2

Mount corner posts (4X)
Secure glass with washers and caps.





NOTE!

Plastic washers protect **both** sides of glass

3

Mount eraser and marker tray on bottom edge.






CLARITY™ Custom Print Glass

Dry Erase - Mounting Instructions

INS622-2 REV A

(2 of 2)

Template board
holds 2 prints



Design your own custom print

Choose from a variety of templates
available online:

www.icebergcustomwhiteboards.com




Reference Chart

Glass Size	Paper Size
11 x 13.5"	8.5 x 11"
13.5 x 19.5"	11 x 17"
18.5 x 24.5"	16 x 22"
24.5 x 36.5"	22 x 34"


4

Changing prints after board is mounted to wall.



5

Using prints you've created.



TIPS

Don't want to tape over the originals?
Cut some cardboard to size and use it
as a makeshift backer board.