



We strive to ensure that our products are of the highest quality and free of manufacturing defects or missing parts. However, if you have any problems with your new product,

DO NOT RETURN IT TO THE STORE,

please contact us toll free @:

1-888-996-2729

FAX: 1-866-873-3531

gameroom@escaladesports.com

Mailing Address: (Correspondence Only)

Escalade Sports
PO Box 889
Evansville, Indiana 47706-0889

Physical Location:

Escalade Sports
817 Maxwell Ave.
Evansville, Indiana 47711

Please visit our Web site at:

www.escaladesports.com

Please have your model number when inquiring about parts.

When contacting Escalade Sports please provide your model number, date code (if applicable) and part number if requesting a replacement part. These numbers are located on the product, packaging, and this owners manual.

Your Model Number **D5660F**

Date Code **2 - D5660F- - JL**

Purchase Date _____

PLEASE RETAIN THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE

**IMPORTANT! READ EACH STEP
IN THIS MANUAL BEFORE YOU
BEGIN THE ASSEMBLY.**

IMPORTANT!

THE DRAWINGS IN THIS
MANUAL MAY BE
EXAGGERATED OR MODIFIED
TO SHOW DETAILS.



TWO SIDED OVER THE DOOR AXE THROW

No Tool Required

PARTS IDENTIFIER (Not to Scale)



P1 - Double Sided Throwing
Target
(1 pc)

Side 1 - High Score

Side 2 - Battle Axe



P2 - Soft Foam Axe
(3 pcs)



P3 - Door Hook
(1 pc)



P4 - Carry Bag
(1 pc)


PARTS REQUIRED

1pc - **P1** Double Sided Throwing Target

1pc - **P3** Door Hook

Step 1 Mounting Instructions

Center and place the Door Hook (**P3**) over the door, then hang the Target (**P1**) as shown below.



WARNING: This is not a toy and is intended for use by or under the supervision of adults. Axe should only be thrown at the target. Ensure the throwing lane is clear of people or pets when playing this game. Impact from axe could cause physical harm, injury or property damage. Discard axe if damaged.

Storage Instructions

Fold Target (**P1**) as shown in steps 1-4. Then, store Target (**P1**), Foam Axes (**P2**) & Door Hook (**P3**) in the Carry Bag (**P4**).

NOTE: Unfolded Target dimension is 26".



Game Rules



HIGH SCORE GAME

1. Players will each be given one axe to throw towards the center of the target. The closest player to the middle of the board will earn the right to throw first.
2. Players will throw 3 axes in one turn of play. Simply count up the points scored in each round.

The player who scores the most points in each round earns 1 point. The player with the most points after 10 rounds is the winner. In case of a 5-5 tie, you will go to overtime play and the first player to hit the bullseye wins. Both players **MUST** get at least one chance or round of 3 axes to hit the bullseye. If either team does not hit the bullseye in the first round of overtime play, game play is then moved to “sudden death” which means the first player to hit the bullseye is the automatic winner and the game is over. If **BOTH** players hit the same amount of bullseye in the first round, both teams automatically get another chance to throw for bullseye. If a player hits more bullseyes than the other player in overtime play, they are the instant winner as well.
3. Point values are awarded for Axes that are touching the majority of the point value on the target.
4. For axes that look to be 50% split between point values, the higher point value will be awarded.
5. Axes that miss the target count as a throw and zero points are awarded.
6. Axes that bounce out or are knocked out by another axe count as a throw and zero points.
7. Axes that stick to the back of another axe thrown counts as zero points.

Game Rules (continued)



BATTLE AXE GAME

Players will each be given one axe to throw towards the center of the target. The closest player to the middle of the board will earn the right to throw first.

1. The first player to throw in each round is the “attacker” and the second player is the “defender”.
2. Players will alternate being the “attacker” and “defender” in each round of play.
3. The “attacker” will throw 3 axes and add up the total score for that round. The defender will then throw 3 axes and add up their total. The “attacker” **MUST** have a higher point total in the round than the defender to earn a point for the round. Only the “attacker” can earn points. If the “defender” scores higher than the attacker in any given round, they used their shield well and no points are awarded.
4. Play will continue until 5 points are earned as the attacker.
5. Point values are awarded for Axes that are touching the majority of the point value on the target.
6. For axes that look to be 50% split between point values, the higher point value will be awarded.
7. Axes that miss the target count as a throw and zero points are awarded.
8. Axes that bounce out or are knocked out by another axe count as a throw and zero points.
9. Axes that stick to the back of another axe thrown counts as zero points.

PRODUCT PARTS LIST FOR MODEL # D5660

Key #	Part #	Description	Qty.
P1	D5660JLP1	Double Sided Throwing Target	1
P2	D5660JLP2	Soft Foam Axe	3
P3	D5660JLP3	Door Hook	1
P4	D5660JLP4	Carry Bag	1

90 DAY LIMITED WARRANTY

This customer warranty extends to the original owner, on the purchase of any ESCALADE SPORTS Product (hereinafter referred as the "Product").

WARRANTY DURATION: This Product is warranted to the original owner, for a period of 90 days from the original purchase.

WARRANTY COVERAGE: ESCALADE SPORTS warrants to the original owner, this product to be free from defects in material and workmanship when used for the intended purpose under normal use and conditions. THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN DAMAGED BY ACCIDENT, UNREASONABLE USE, NEGLIGENCE, IMPROPER SERVICE, FAILURE TO FOLLOW INSTRUCTIONS PROVIDED WITH THE PRODUCT OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIAL AND WORKMANSHIP.

WARRANTY REPLACEMENT: During the above 90 day warranty period, ESCALADE SPORTS shall provide replacement components or replace with a comparable product at our choosing. If product is defective under normal use and proper care, please contact our Customer Service Dept.

1-888-996-2729 / Customer Service Dept.

Or Write us at:

Escalade® Sports, Inc. - P.O. Box 889, Evansville, IN 47706

Attn: Customer Service Dept.

Or E-mail us at:

customerservice@escaladesports.com

Other than shipping requirements no charge will be made for such replacement of in-warranty Products.

WARRANTY DISCLAIMERS: ANY IMPLIED WARRANTIES ARISING OUT OF THIS SALE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE ABOVE 90 DAY PERIOD. ESCALADE SPORTS SHALL NOT BE LIABLE FOR LOSS OF USE OF THE PRODUCT OR OTHER CONSEQUENTIAL OR INCIDENTAL COSTS, EXPENSES OR DAMAGES INCURRED BY THE CONSUMER OF ANY OTHER USE.

Some states do not allow the exclusion or limitation of implied warranties or consequential or incidental damages, so the above limitations or exclusions may not apply to you.

LEGAL REMEDIES: This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.