



WWW.RAVESPORTS.COM

Performance SUP Paddle **Instructions**

To adjust the paddle height, unlatch the collet, and simply adjust to desired height. To tighten the collet, turn in a clockwise direction and latch.

When adjusting your paddle generally, the paddle height should be 8-10 inches above the paddler's height. Starting with no shoes on and arm raised, your paddle handle should sit in your palm.

Copyright © 2017

All rights reserved. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopy, recording, or any information storage and retrieval system, without permission in writing from the publisher. Requests should be mailed to RAVE Sports, 985 Aldrin Drive #301, Eagan MN, 55121

June 2017