




PATRIOTIC 100mm BOCCE BALL SET

INSTRUCTION MANUAL



PLEASE KEEP THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE

If you have any concerns with your product please visit our website www.escaladesports.com for fastest service. Please have a copy of your receipt of purchase. For any technical support or warranty issues please contact Escalade Sports at 1-800-467-1421 or e-mail us at customerservice@escaladesports.com

Limited 90-Day Escalade Sports Warranty

All Escalade Sports games have a limited 90-day from date of purchase warranty. This warrants the retail purchaser for any Escalade Sports game purchased to be free from any defect in materials and construction for 90 days from the date of purchase. The only exceptions to the warranty include main frames, tabletops, playing surfaces, batteries or tools. Damaged main frames, tabletops, playing surfaces need to be returned to the store as we are unable to replace these parts. Normal play wear and usage is not covered under the warranty, nor is wear or damage due to improper use of the Escalade Sports game. This will void any and all Escalade Sports warranties.

A PURCHASE RECEIPT (or other proof of purchase date) will be required before any warranty service is initiated. All requests for warranty service can be submitted by email, in writing or by contacting our Customer Service Department at: 1-800-467-1421 or email us at customerservice@escaladesports.com

IMPORTANT NOTICE! Please contact us before returning the product to the store.

Warnings



Not for use by children without adult supervision. This is not a child's toy. Adult supervision is required for children playing this game. Please read instructions carefully.

Be sure to check out all the exciting games Escalade Sports has to offer. Visit our web site at:

ESCALADE
SPORTS

ESCALADESPORTS.COM



Bag Toss



Net Games



Lawn Games

Escalade Sports

Physical Location:

817 Maxwell Ave.
Evansville, IN 47711


Mailing Address: (Correspondence Only)

PO Box 889
Evansville, IN 47706

Parts List

1

Bocce Ball - Blue



Qty. 2 (Stars)
Qty. 2 (Stripes)

2

Bocce Ball - Red



Qty. 2 (Stars)
Qty. 2 (Stripes)

3

Jack/Pallino



Qty. 1

4

Measuring Device



Qty. 1 Set

5

Carry Bag



Qty. 1


NOTE: Game can be played outdoors but must be stored indoors in a dry place.

Game Rules

Bocce For Beach or Backyard

The object is to score the most points by ending each round with your color balls closest to the jack (white point ball). Toss a coin to determine the person who will throw the jack at least half way down the designated playing area. The same person who tossed the jack then throws one ball, trying to get it as close to the jack as possible. Team Two then throws, trying to get a ball closer to the jack than Team One. If Team Two gets closer, then it is Team One's turn. If Team Two's ball does not come closer, then they continue to throw until they get a ball closer to the jack than Team One or until they run out of balls. Then Team One throws their balls. You can knock your opponent's balls away from the jack to increase your score. Use measuring device for close calls.

Scoring: At the end of each frame the team closest to the jack will get a point for each ball that is closer than the closest opponent's ball. The game is usually played to 12 points.



**See Illustration above for the recommended Tournament Court size. However, the court can be made to any size, to fit the space available.*