

WLK Woodland Media Kit Installation Instructions

WARNING

- Do not touch safety screen until cooled.
- Allow safety screen to cool completely before any maintenance, as it will remain hot after appliance is no longer operating.
- To avoid danger of suffocation keep the packaging bag away from babies and children. Do not use in cribs, bed, carriages, or play pens. This bag is not a toy. Knot before throwing away.

note:

Images are for illustrative and placement purposes only. Actual Woodland Media Kit components will appear differently.



Glass



Glowing Embers



Splinters



Rocks



Charcoal



Vermiculite

1. Install logs (if supplied or purchased) as per manual/leaflet instructions supplied with the logs.
2. Install **glass** (supplied) around the logs, burner, and, if applicable, mesh area to allow lights to shine through (**Fig. 1**).




Fig. 1

3. Thinly separate the **glowing embers** and place them on the burner. Avoid covering the large cluster of ports, as this will turn the flame blue instead of orange (**Fig. 2**).




Fig. 2

4. Place **splinters** around the glass along the outer part of the media tray (**Fig. 3**).




Fig. 3

5. Place **rocks** randomly in the larger voids of the previously placed media. Do not cover the burner.
6. Spread **charcoal** randomly on top of the other media. Do not cover the burner.
7. Spread **vermiculite** randomly on top of the other media. Do not cover the burner.

Instructions d'installation du kit multimédia WLK Woodland

! AVERTISSEMENT

- Ne touchez pas l'écran de protection jusqu'à ce qu'il ait refroidi.
- Laissez l'écran de protection refroidir complètement avant d'effectuer un entretien, car il demeurera chaud après l'arrêt de l'appareil.
- Afin d'éviter les risques de suffocation, gardez le sac d'embellage loin des bébés et des jeunes enfants. Ne le laissez pas traîner dans les berceaux, les lits, les poussettes ou les parcs de jeu. Ce sac n'est pas un jouet. Nouez-le avant de le jeter.

note:

Les images sont uniquement à des fins d'illustration et de placement. Les composants réels du kit multimédia Woodland apparaîtront différemment.



Vitre



Braises
Incandescentes



Éclats



Roches



Charbon de Bois



Vermiculite

1. Installez les bûches (si fournies ou achetées) conformément aux instructions du manuel/de la notice fournies avec les bûches.
2. Installez **la vitre** (fournie) autour des bûches, du brûleur et, le cas échéant, de la zone grillagée pour permettre aux lumières de briller à travers (**Fig. 1**).





Fig. 1

3. Séparez finement **les braises incandescentes** et placez-les sur le brûleur. Évitez de couvrir le grand groupe de ports, car cela rendra la flamme bleue au lieu d'orange (**Fig. 2**).





Fig. 2

4. Placez **les éclats** autour de la vitre le long de la partie extérieure du bac média (**Fig. 3**).





Fig. 3

5. Placez **des roches** au hasard dans les plus grands vides des supports précédemment placés. Ne couvrez pas le brûleur.
6. Étalez **le charbon de bois** au hasard sur les autres supports. Ne couvrez pas le brûleur.
7. Étalez de **la vermiculite** au hasard sur les autres supports. Ne couvrez pas le brûleur.