

Spin Wheel™

Owner's Manual



WWW.RAVESPORTS.COM

Copyright © 2017

All rights reserved. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopy, recording, or any information storage and retrieval system, without permission in writing from the publisher. Requests should be mailed to RAVE Sports, 985 Aldrin Drive #301 Eagan, MN 55121. 800.659.0790

Table of Contents:

Introduction	3
Safety rules and information.....	4
Spin Wheel.....	6
Assembling your Spin Wheel	7
Attaching the Bongo	9
Anchoring Spin Wheel.....	10
Folding.....	11
Cleaning and storage	13
Repair.....	14

Package Contents:

Qty 1- Spin Wheel Track

Qty 1- Repair Kit, owner manual, warranty card

Qty 1 – Air Compressor Inflation Adaptor w/Gauge

Date Purchased: _____

Purchased from: _____

Serial Number: _____

(The serial # is located by the inflation valve. Having this number handy will assist you in finding accurate parts and information for your specific product.)

**Staple your sales
receipt here.**

Introduction

Thank you for purchasing a RAVE Sports® Spin Wheel™. This Owner's Manual is presented to enhance your enjoyment of the sport and is intended to alert you to some of the potentially dangerous conditions that can arise in all water sports. It also contains important safety instructions and information about how to assemble, use and care for your product.

Please take a few minutes to read this manual before assembling and using the product. Although the product is simple to use, this manual contains important safety information that you and all users must understand to safely enjoy the Spin Wheel.

Make sure that everyone who uses the product also receives proper education and supervision and understands the safety instructions and warnings presented in this manual. Be sure to save this manual for future reference.

IMPORTANT: *This Spin Wheel Attachment was designed to be used only with the RAVE Sports Bongo 13. Do not attempt to attach to any other products or use it in any other manner than its designed and intended use as described herein.*

If you have any questions regarding this product, please call RAVE Sports at 1-800-659-0790 or visit www.ravesports.com. Please have your serial number available.

WARNING

**UNSAFE USE OF THE SPIN WHEEL CAN
RESULT IN PERSONAL INJURY OR DEATH.**

**TO REDUCE THE RISK OF INJURY, READ AND FOLLOW ALL
INSTRUCTIONS AND WARNINGS IN THIS MANUAL. DO NOT
USE THIS PRODUCT UNLESS YOU UNDERSTAND AND
ACCEPT THE RISK OF INJURY INVOLVED WITH THIS
ACTIVITY.**

Safety Rules and Information

- Read and understand all of the information contained in this owner's manual before assembling and using your product.
- Make sure that everyone who uses the product is provided with and understands these safety rules and information.
- The Spin Wheel is designed to be used on large bodies of water with a depth of at least 5 feet (1,5m) of water. Do not use or allow anyone else to use this product in swimming pools on land or any other hard surfaces.
- Maximum Capacity allowed on the product - Track: 15 Users totaling 2,500 lbs/ (1134kg). Center Hub (Bongo 13): 4 users (700lbs/318kg).
- Choose a location for your product that is most protected from wind, of sufficient water depth, and free of obstructions in all directions.
- Always anchor the Spin Wheel securely before it is used.
- Always wear a U.S. Coast Guard approved Type III personal flotation device (PFD) when using the Spin Wheel.
- Never use the product after sunset, before dawn, or any other time in poor lighting conditions.
- Never use the product in rough surface water conditions, during storms, or when there is lightning. If an unexpected storm arises while using the product, seek shelter on shore. Do not stay on the product.
- Never use the product under the influence of alcohol or drugs.
- Do not connect directly to docks, piers or other hard objects.
- Never tow from a boat or other motorized vehicle, while people are on the product.
- To avoid the possibility of a collision, make sure area around the Spin Wheel is clear of obstructions and other swimmers before each use.
- Drowning Hazard: Never swim or play under the Spin Wheel.
- Never use the product while tired or fatigued. Use extreme caution while swimming between the shore and the product. Do not attempt to swim this distance if you are tired or fatigued.
- Always inspect the areas around and under the product before each use to ensure the water is deep enough and free of all rocks, logs, sand bars, and underwater obstructions and that the product is a safe distance from above water hard objects.
- Ask about local water conditions before using the product in unfamiliar water.
- Inspect your product for any worn, defective, or missing parts. Do not use if there are any signs of damage, wear or deterioration. Replace or repair before use.

- Never dive off the product head first. If jumping off the product, always enter the water feet first.
- Not recommended for children under the age of six. Use the Spin Wheel only under mature, knowledgeable adult supervision.
- The surface of the Spin Wheel will get wet and slippery. Always exercise caution and common sense while using the Spin Wheel. Reckless behavior may result in serious injury.
- Do not attempt or allow flips, somersaults or other acrobatic maneuvers. Landing on the head or neck can cause serious injury, paralysis or death.
- When not in use, secure the product against unauthorized or unsupervised use.
- Do not use in shark infested water or in water that may contain other marine life dangerous to humans.
- Ensure proper air pressure is maintained while the product is in use. Check air pressure frequently especially on very hot/cold days.
- This device is not designed to be used as a life saving device.
- Take off watches, rings and other sharp objects before use.

Liability

While every attempt is made to embody the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

Spin Wheel

(Item #02665)

Product	Minimum Water Depth	Maximum Capacity	Maximum Weight	Working Pressure
Spin Wheel	5 ft (1, 5m)	15 Users	2,500lb (1134kg)	8 psi (0, 55bar)




Assembling your Spin Wheel™ Track

Inflation

Roll out and unfold the Spin Wheel on flat ground. Make sure the area is free of rocks, sticks or other sharp objects that could puncture or damage the product.

We highly recommend using the RAVE High Speed Inflator/Deflator. It will provide rapid inflation and deflation. (*Item #01083, not included*)



To lock open valve, depress the stem and rotate $\frac{1}{4}$ turn clockwise. To close valve, depress the stem and rotate $\frac{1}{4}$ turn counter-clockwise. The valve stem should be in the depressed position while inflating. Replace cap on valve after inflation to ensure air tight seal.

If you are using the RAVE Sports High Speed Inflator (*Item #01083*), simply lock the adaptor onto the end of the inflation hose and insert into the valve body. Turn $\frac{1}{4}$ turn to lock in place.



NOTE: This inflation adaptor will automatically open the valve when inserted and will close the valve when removed. You do not need to manually open/close the valve when using this special adaptor.

USE the RAVE Air Compressor valve adaptor provided with the Spin Wheel to finish inflating Spin Wheel track to approx. 5 psi Min – 8 psi Max. This will be rigid enough to support 15 users.



DO NOT INFLATE Spin Wheel beyond 8 psi. Doing so will cause damage thus voiding warranty. Use the RAVE Air Compressor adaptor gauge to ensure correct air pressure.

To Deflate:

Rapid deflation can be achieved using the “deflate” side of the motor housing. Attach the hose to the deflate side of the motor housing and lock the valve adaptor into the valve.

Move to Water

Due to its size, use 5 or more people to carry the product to the water

CAUTION: To avoid risk of puncture or damage to the product, ***DO NOT DRAG the product.*** Always carry it to the water. Float the Spin Wheel to the desired location for anchoring.

CAUTION! The surface of the Spin Wheel can become wet and slippery. Refrain from horseplay or other activity that could cause collisions and falls, resulting in injury.

⚠ WARNING: DROWNING HAZARD

NEVER ATTEMPT TO SWIM UNDER THE SPIN WHEEL.
THE SPIN WHEEL IS A LARGE OBJECT ON THE WATER WITH NO
PLACE TO COME UP FOR AIR IF YOU ARE BENEATH IT.

The Spin Wheel is only designed to be attached to the RAVE Sports Bongo 13. Follow inflation instructions provided with the Bongo 13.



WARNING



Do not attempt to use the Spin Wheel Track without the Bongo 13
securely attached in the center.

Attaching to Bongo 13

Note: Do all attachments in shallow water.

Step 1

Lift and slide the Bongo 13 over the Spin Wheel track and into the center. Make sure the blue panels of the Bongo 13 are aligned with the spokes on Spin Wheel.




Step 2

Slide the straps that have the Velcro flaps in through the center opening of the Bongo13 jump surface loops. (As seen in Step 3)

Step 3

NOTE: One person will need to be underneath the Bongo 13 for this step.

Take the bottom strap and wrap it around the bottom of the tube and feed it through the stainless steel buckle. Pull down until it is tight. Tie a knot immediately adjacent to the buckle to prevent any possibility of slippage.





Step 4


When all the straps are tightly cinched down and tied off, fold the two flaps inward and velcro it together over buckles and straps.

Anchoring

There is one anchor attachment point at the center of the Spin Wheel. Attach anchor line to the lower ring on swivel. **Note: Do not use the anchor point on the Bongo 13. Attach anchor line only to this swivel for proper operation.**



Remove all slack from anchor line and secure to swivel. Make sure the swivel is free to rotate. **We recommend the (RAVE Anchor Connector Kit #01024).**



The Spin Wheels is ready to use.

Maximum Capacity allowed on the product

- Track: 15 Person 2,500 lbs/ 1134 kg
- Center hub: 4 Person 700 lbs/318 kg

Folding Instructions

Step 1

Remove Bongo 13 from Spin Wheel Track while in shallow water.

Step 2


Carry the Spin Wheel Track to land and deflate it. Be extremely careful not to drag the product.

Step 3

Let the mat dry completely in the sun and then flip over and repeat for the other side. (Dry with a towel, if necessary, to ensure it is completely dry before folding). If there is algae build up, clean it off with a stiff bristle brush to clean it off.


Step 4

Lay the Spin Wheel out and fold it according to the photos and diagrams provided on page 12.




Folding the Spin Wheel step by step diagram


1. Start by folding two **opposite sides** towards the center.




2. Next begin rolling from a side **adjacent** to the center.




3. Continue rolling the mat upon itself while keeping the roll **as tight as possible**.




4. Roll until the **middle** is reached.





4. Roll until the **middle** is reached.




5. Now begin rolling the **opposing end** toward the **middle**.




6. Continue rolling while making sure to keep the roll **as tight as possible**.



7. Finish rolling until **middle** is reached.



8. Start at one end and roll to the other end to create a bundle.
p.11



Cleaning and Storage

- When the inflatable product is not being used, store it in a covered, shaded area. This will help protect it against ultraviolet (UV) rays and extend the life of the product.
- Clean the inflatable completely with a mild soap and fresh water. NEVER USE PETROLEUM BASED PRODUCTS OR SOLVENTS FOR CLEANING. NEVER USE A POWER WASHER SINCE THE HIGH PRESSURE WATER JET WILL DAMAGE THE TUBE BEYOND REPAIR.
- Product should be completely dry and remain dry while stored.
- Roll the product loosely and place in a container, preferably one that rodents can't chew through.
- Secure against unauthorized or unsupervised use.
- Store in a cool, dry location. Do not store product directly on concrete surface. Place mothballs around stored inflatable to keep mice and insects away.

..... **Important**

Rodents like muskrats may be attracted to the PVC vinyl of your product.

When your product is on the water, maintaining full air pressure during periods of non-use will discourage them from chewing the vinyl.

Another way to ease the problem of nuisance rodents is to remove the temptation by taking the product out of the water at night. You can also make the whole area unattractive to rodents by changing the environment, making the area less hospitable for rodents. Removing any food source from the shoreline can also be a good deterrent. Check with your local DNR for additional guidance or possible restrictions

Repairs

For large holes, tears or seam failures, contact RAVE Sports at 1-800-659-0790.

Additional repair patches can be found online at www.ravesports.com.

For minor holes and tears:

- Inflate the product and locate the leak by spraying the tube with mild soapy water.
- Determine the hole size and cut a patch 1-2 inches wider than the diameter of the hole. Make sure all corners of the patch are rounded.
- Deflate the product and clean the patch and area around the hole with rubbing alcohol. Let dry completely.
- READ AND UNDERSTAND THE WARNINGS ON THE GLUE CONTAINER.
- Apply glue to the patch and the area around the hole. Let the glue dry until it is tacky to the touch. (About 30 seconds).
- Lay the product on a flat, hard surface and apply the patch. Working from the center to the outer edge, rub out any air bubbles between the patch and the product.
- Let patch dry for 24 hours before attempting to inflate the product.

RAVE
SPORTS®

RAVE
SPORTS®

THIS PAGE INTENTIONALLY LEFT BLANK.

RAVE
SPORTS®

RAVE
SPORTS®



WWW.RAVESPORTS.COM

RAVE SPORTS
A Revel Match, LLC Company
985 Aldrin Drive #301
Eagan MN, 55121
800.659.0790

June 2017