



Universal Traditional SUP Carry Bag Instructions

Note: This bag accommodates SUP board sizes 10'6" - 11'6" and 34" max width


1. Lay the bag with the fin zipper up.
2. Slide SUP board into bag fin side up and forward to nose end of bag. (Optional: Insert fin into fin pocket for storage.)
3. If excess space is available, push board all the way towards the tail of the bag.
4. Fold the excess over and buckle it into place.
5. Cinch the strap then fold excess strap and tuck it into loop for a clean look.
6. Utilize shoulder strap and center handle strap for easy carry
7. Center loops allow paddle to be inserted and used as a handle to carry bag.
8. For shorter boards, use the outer loop and for taller boards use the inner loop.

WARNING:

Do not store in the sun for long periods of time. Allow ventilation by fully opening the fin zipper to allow heat to escape bag.

CLEANING:

Use soft towel and warm soap water to wipe down the inside.



© Copyright 2017

All rights reserved. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopy, recording, or any information storage and retrieval system, without permission in writing from the publisher. Requests should be mailed to RAVE Sports, 985 Aldrin Drive #301, Eagan MN, 55121



WWW.RAVESPORTS.COM

RAVE SPORTS

A Revel Match, LLC Company

985 Aldrin Drive #301

Eagan MN, 55121

800.659.0790

June 2017