



We strive to ensure that our products are of the highest quality and free of manufacturing defects or missing parts. However, if you have any problems with your new product,

DO NOT RETURN IT TO THE STORE,

please contact us toll free @:

1-866-556-2758

FAX: 1-866-873-3531

tablehockey@escaladesports.com

Or write to:

Escalade Sports

Customer Service Department

P.O. Box 889

Evansville, IN 47706

Please visit our Web site at:

www.escaladesports.com

Please have your date code when inquiring about parts.

When contacting Escalade Sports please provide your model number, date code (if applicable), and part number if requesting a replacement part. These numbers are located on the product, packaging, and in this owners manual.


Your Model Number **G03509W**

Date Code: **2-G03509W-0410-WJ**

Purchase Date: _____

PLEASE RETAIN THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE

**IMPORTANT! READ EACH STEP
IN THIS MANUAL BEFORE YOU
BEGIN THE ASSEMBLY.**



TWO ADULTS ARE REQUIRED TO ASSEMBLE THIS GAME TABLE

Tools Required:

Allen Wrench T1-Included with the table
Philips Screwdriver
Furniture Polish and Cloth

An electric screwdriver is helpful in assembly. However, please set at low torque and use extreme caution with an electric screwdriver because you could overtighten the hardware and strip the screws.

Assembly Tips

Make sure you understand the following tips before you begin to assemble your hockey table.

1. Start all bolts by hand before tightening.
2. Some drawings or images in this manual may not look exactly like your product. Please read and understand the text before starting each assembly step.




WARNING:

**READ AND FOLLOW ALL ASSEMBLY, OPERATION, AND
SAFETY INSTRUCTIONS CAREFULLY. AT LEAST TWO
ADULTS ARE NEEDED TO PUT THIS GAME TABLE
TOGETHER.**


HARDWARE IDENTIFIER (To Scale)




H1-M8 x 45mm
Allen Head Bolt(12)



H2-M8 Flat
Washer(12)



H3-M3 x 18mm
Washer Head
Screw(32)




(Not to Scale)


T1-Allen
Wrench(1)

PARTS IDENTIFIER


(Not To Scale)




P1-Main Hockey
Cabinet (1)




P2-Right Leg(2)




P3-Left Leg(2)



P4-Curved Outside
Leg Panel(2)




P5-Flat Inside Leg
Panel(2)



P6-Leg Leveler
(4)

ACCESSORY IDENTIFIER

(Not To Scale)



A1-Red Striker(4)



A2-Red Puck(4)



A3-Felt Pad(4)

PARTS REQUIRED:


- 12 pcs - **H1** Allen Head Bolt
- 12 pcs - **H2** Flat Washer
- 2 pcs - **P2** Right Leg
- 2 pcs - **P3** Left Leg
- 1 pc - **T1** Allen Wrench

STEP 1:

To assemble this table, leave the **P1** Main Hockey Cabinet face down in the carton lid. As shown in **Figure 1**, attach the **P2** Right Legs and **P3** Left Legs on the inside of the frame with **H1** Allen Head Bolts and **H2** Flat Washers. Use the **T1** Allen Wrench to tighten the bolts.

CAUTION:

FOR CORRECT LEG PANEL INSTALLATION, PLEASE BE SURE TO ASSEMBLE **P2-RIGHT LEGS** AND **P3-LEFT LEGS** EXACTLY AS PER DIAGRAM.



PARTS REQUIRED:

32 pcs - **H3** Washer Head Screw
2 pcs - **P4** Curved Outside
Leg Panel
2 pcs - **P5** Flat Inside Leg Panel
4 pcs - **P6** Leg Leveler

STEP 2:

Attach each **P5** Flat Inside Leg Panel as shown in **Figure 2**. Align the holes in the panel with pilot holes in the legs then secure with **H3** Washer Head Screws as shown. Repeat the above procedure to attach each **P4** Curved Outside Leg Panel then secure with **H3** Washer Head Screws.

Thread the **P6** Leg Levelers into each leg as shown in **Figure 2**.




Figure 2

**WARNING:**

THIS STEP REQUIRES TWO OR MORE ADULTS.

VERY CAREFULLY TURN THE TABLE OVER AND SET IT ON ITS LEGS. BE CAREFUL. THE TABLE IS VERY HEAVY.

STEP 3:

Peel the backing off **A3** Felt Pad and attach to **A1** Striker as shown in **Figure 3**.





Figure 3

Congratulations! You have now assembled your hockey table. Please note the Care and Use instructions below to ensure many years of trouble free use of your game table.

Operation of the game

1. Plug the blower motor and the adapter into the outlet box under the table.
(This step is completed at factory)



2. Plug the cord coming out of the control box into a suitable 120V household outlet.
NOTE: Place cord in nearest outlet to minimize trip hazard.
Never set objects on cord.
3. From the control box, turn the main power on to activate the blower motor.
4. Turn on scoreboard switch to activate the electronic scoring.
5. Press minutes button to select the time limit of your game - 15 minutes, 10 minutes, 5 minutes or freeplay (no time limit).
6. Press the reset button to start your game.

CARE AND USE OF YOUR TABLE

1. For long life and best play from your air hockey table, apply spray furniture polish to a clean cloth and wipe down the playfield with air motor running to make the pucks slide faster before first play and frequently thereafter.
You may use spray furniture polish to clean all exterior surfaces.
2. This product is intended for **INDOOR** use only.
3. **DO NOT** operate the motor if the cord is damaged in any way.
4. **DO NOT** sit, climb or lean on the table.
5. **DO NOT** drag the table when moving it. This will damage the legs.
6. **DO NOT** set drinks on the table.

TABLE HOCKEY RULES

The Object of the Game

To score a predetermined number of points or to score the most points in a given amount of time.

To Play

Flip a coin to determine who will begin play. Play begins when the puck is placed on the playing surface. Players must hit the puck with the striker and attempt to shoot it into their opponent's goal. One point is awarded when a puck is shot into the opponent's goal.

Sometimes pucks can fly off the table. If this occurs, players may take turns placing the puck back on the table.

PRODUCT PARTS LISTS

Part#	Description	Qty	Part#	Description	Qty
03509WJH1	M8 x 45mm Allen Head Bolt	12	03509WJA2	Red Puck	4
03509WJH2	M8 Flat Washer	12	03509WJA3	Felt Pad	4
03509WJH3	M3 x 18mm Washer		03509WJA4	Adapter	1
	Head Screw	32	03509WJC1A	Sensor (Short Wire)	1
03509WJT1	Allen Wrench	1	03509WJC1B	Sensor (Long Wire)	1
03509WJP1	Main Hockey Cabinet (No Blower Motor)	1	03509WJC2	Main Electronic Unit	1
03509WJP2	Right Leg	2	03509WJC3	Control Panel	1
03509WJP3	Left Leg	2	03509WJC4A	Electronic Display (Short Wire)	1
03509WJP4	Curved Outside Leg Panel	2	03509WJC4B	Electronic Display (Long Wire)	1
03509WJP5	Flat Inside Leg Panel	2	03509WJC5	Blower Motor	1
03509WJP6	Leg Leveler	4	03509WJK1	Hardware Kit	1
03509WJA1	Red Striker	4	03509WJM1	Owners Manual	1

90 DAY LIMITED WARRANTY

This customer warranty extends to the original owner, on the purchase of any ESCALADE SPORTS Product (hereinafter referred as the "Product").

WARRANTY DURATION: This Product is warranted to the original owner, for a period of 90 days from the original purchase.

WARRANTY COVERAGE: ESCALADE SPORTS warrants to the original owner, this product to be free from defects in material and workmanship when used for the intended purpose under normal use and conditions. THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN DAMAGED BY ACCIDENT, UNREASONABLE USE, NEGLIGENCE, IMPROPER SERVICE, FAILURE TO FOLLOW INSTRUCTIONS PROVIDED WITH THE PRODUCT OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIAL AND WORKMANSHIP.

WARRANTY REPLACEMENT: During the above 90 day warranty period, ESCALADESPORTS shall provide replacement components or replace with a comparable product at our choosing. If product is defective under normal use and proper care, please contact our Customer Service Dept.

1-866-556-2758 / Customer Service Dept.

Or Write us at:

Escalade® Sports, Inc. - P.O. Box 889, Evansville, IN 47706

Attn: Customer Service Dept.

Or E-mail us at:

tablehockey@escaladesports.com

Other than shipping requirements, no charge will be made for such replacement of in-warranty products.

WARRANTY DISCLAIMERS: ANY IMPLIED WARRANTIES ARISING OUT OF THIS SALE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE ABOVE 90 DAY PERIOD. ESCALADE SPORTS SHALL NOT BE LIABLE FOR LOSS OF USE OF THE PRODUCT OR OTHER CONSEQUENTIAL OR INCIDENTAL COSTS, EXPENSES OR DAMAGES INCURRED BY THE CONSUMER OF ANY OTHER USE.

Some states do not allow the exclusion or limitation of implied warranties or consequential or incidental damages, so the above limitations or exclusions may not apply to you.

LEGAL REMEDIES: This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.