

Sky Totter™

(Euro Totter *in Europe*)

Owner's Manual



WWW.RAVESPORTS.COM

Copyright © 2017

All rights reserved. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopy, recording, or any information storage and retrieval system, without permission in writing from the publisher. Requests should be mailed to RAVE Sports, 985 Aldrin Drive #301 Eagan, MN 55121. 800.659.0790

Table of Contents

Introduction.....	2
Safety Rules and Information	2
Sky Totter/ Euro Totter	5
Inflation	6
Anchoring	8
Maintenance	10
Cleaning	11
Storage and Repairs	12

Contents in this package:

- Sky Totter/ Euro Totter
- Warranty registration
- Repair kit

Please make sure you have received the contents listed, and then record the following information for future reference.

Date Purchased: _____
Purchased from: _____
Serial #: _____

(The serial # is located by the inflation valve. Having this number handy will assist you in finding accurate parts and information for your specific product.)

**Staple your sales
receipt here.**

Introduction

Water sports can be safe and fun for all levels of enthusiasts. The Owner's Manual is presented to enhance your enjoyment of the sport. It is intended to alert you to some of the potentially dangerous conditions that can arise in all water sports.

Please take a few minutes to read this manual before assembling and using the product. Although the product is simple to use, this manual contains important safety information that you and all users must understand to safely enjoy this product.

If you have any questions regarding this product, please call RAVE Sports at 1-800-659-0790, or visit www.ravesports.com. Please have the serial number from your product ready when you call.

WARNING

UNSAFE USE OF THIS PRODUCT CAN RESULT IN PERSONAL INJURY OR DEATH.

To reduce the risk of injury, read and follow all instructions and warnings in this manual. Do not use this product unless you understand and accept the risk of injury involved with this activity.

Safety Rules and Information

- Read and understand all of the information contained in this owner's manual before assembling and using your product.
- Make sure that everyone who uses the product is provided with and understands these safety rules and information.
- This product is designed to be used in large bodies of water with depths of at least 6 feet (1,8m) of water. Do not use or allow anyone else to use the product in swimming pools, or on land.

- Choose a location for your product that is most protected from wind, of sufficient water depth, and free of obstructions.
- Always anchor the product securely before it is used on water.
- Always wear a U.S. Coast Guard approved Type III (PFD) vest when using the product.
- Never use the product after sunset, before dawn, or any other time in poor lighting conditions.
- Never use the product in rough surface water conditions, during storms, or when there is lightning. If an unexpected storm arises while using the product, seek shelter on shore. Do not stay on the product.
- Never use the product under the influence of alcohol or drugs.
- Always stay under control while using the product.
- Do not allow more than four people totaling 900 lbs. (408 kg) max on the product at the same time.
- Never swim or play under or around the product while it is in use.
- Never dive off of the product head first. If you choose to jump off the product, always enter the water feet first.
- Never use the product while tired or fatigued. Use extreme caution while swimming between the shore and the product. Do not attempt to swim this distance if you are tired or fatigued.
- Always inspect the areas around and under the product before each use to ensure the water is deep enough and free of all rocks, logs, sand bars, and underwater obstructions and that the product is a safe distance from above water hard objects. Ask about local water conditions before using the product in unfamiliar water.
- When not in use, secure the product against unauthorized or unsupervised use.
- Inspect your product for any worn, defective, or missing parts.
- Use only under mature, knowledgeable adult supervision.

- Not recommended for children under the age of six.
- Do not over inflate. Over inflation can cause seam rupture.
- Do not use in shark infested water or in water that may contain other marine life dangerous to humans.
- Ensure proper air pressure is maintained while the product is in use. Check air pressure frequently especially on very hot/cold days.
- This device is not designed to be used as a life saving device.
- Take off watches, rings and other sharp objects before use.

Sky Totter/ Euro Totter

(Item #1000727)

Product	Minimum Water Depth	Maximum Capacity	Maximum Weight	Working Pressure
Sky Totter	6ft (1.8m)	4	900lb (408kg)	2 psi (0,14bar)



INFLATION

SET UP AND SUPERVISION MUST BE DONE BY A MATURE AND KNOWLEDGEABLE ADULT!

You can use the following devices to inflate the Product:


- Electric Inflator/Deflator (household current). RAVE recommends the High Speed Inflator/Deflator, item #01083.

CAUTION: *Use extreme care when using an electric inflator anywhere near water. Beware of the dangers of electrocution when using electric powered inflators. Precautions should be observed during use and handling to prevent shock. Foot / Hand pumps are not recommended for the main chamber due to the size of the product.*

DO NOT inflate with an air compressor or other high pressure pump!! This unit is designed to be inflated with a high volume of air but at a low pressure. Use of an air compressor will void your warranty!

DO NOT allow children to play with the product until it is fully inflated and anchored in the water.

Inflate the main body of the inflatable first unless noted otherwise on Product Page.




To check the exact pressure of your product the use of a RAVE Digital Pressure Gauge (Item #02496) is recommended.

Halkey Roberts Valve – To lock open valve, depress the stem and rotate ¼ turn clockwise. To close valve, depress the stem and rotate ¼ turn counter-clockwise.

The valve stem should be in the depressed position while inflating. Replace the cap on valve after inflation to ensure air tight seal.

A special inflation adaptor is included with this product. If you are using the RAVE Sports High Speed Inflator (Item #01083), simply lock the adaptor onto the end of the inflation hose and insert into the valve body. Turn ¼ turn to lock in place.

NOTE: This inflation adaptor will automatically open the valve when inserted and will close the valve when removed. You do not need to manually open/close the valve when using this special adaptor.



If you will be using another inflation device with a larger nozzle, use the 1 ¼" diameter coupler (included) between the valve adaptor and the hose of your inflator. Make sure the hose is attached to the blower port of the vacuum for inflation. Insert the adapter into the air valve and lock into place by turning clockwise.

DO NOT OVER-INFLATE!! Product should be firm but not hard when properly inflated.

Please Note: Keep in mind the temperature of the air going into the product and the outside air. If your inflator is hot and sending warm air into the product, when it cools, it will seem like your Product is losing air. This is normal.

Weather and temperature variations will also cause the air inside the unit to expand and condense. This is normal. If you are experiencing a cool span you may want to add additional air. Be careful when the temperature rises that the unit does not become over-inflated. Damage due to over-inflation voids the warranty.

Proper inflation should be checked often if the product is left inflated for consecutive days.

All inflatable's are sensitive to cold, therefore never unfold or inflate in temperatures below 50° F (10°C).

WARNING!

Read these materials prior to assembling and using your RAVE Product. Failure to follow these instructions could result in serious injury or death. RAVE Inflatable's are not life saving devices and are meant for swimmers only. Never leave children near water unattended and be sure they are supervised by a mature and knowledgeable adult. RAVE highly recommends the use of U.S. Coast Guard approved personal flotation devices (life jackets) by those near or in the water.

ANCHORING

Due to extreme varieties of conditions, anchor line and anchors are not included with the product and must be purchased separately.

Attach the anchor line (not included) securely to the Anchor Ring(s) on the bottom of the product. The number of anchor attachment points will vary per model.

Please Note: There are many ways to anchor your products. Before moving forward, it is best to consult your local regulations regarding what types of anchors can be used in your area. Every location has different conditions and demands, so you will have to determine what will work best for your situation. Here are a few anchoring tips to get you started.

- Nylon rope holds up the best in water and sun. Lines do eventually wear out, so it's important to check them periodically.
- Choose a location that is most protected from the wind, of sufficient water depth and free of obstructions a safe distance in all directions.

- A minimum of 150-200 lbs. (68-91kg) of anchor weight per anchor point is recommended for most applications; however, larger products on larger bodies of water may require more.
- Bell anchors are not typically recommended since they are easily dragged, especially on flat, sandy bottoms. Screw-type or more permanent toggle-type anchors may be necessary in more extreme conditions.
- Attaching a heavy duty shock cord to the anchor line is recommended to help absorb vertical movements of the product due to waves and normal use. An Anchor Connecting System (part # 01024) is available through RAVE Sports and does include this heavy duty shock cord.
- Adjust length of anchor line so that it is approximately 1-2 ft. (0,3-0,7m) longer than the depth of the water. The RAVE Sports anchor connector shock cord will provide 2-3 ft. (0,7-1m) of stretch to absorb waves and any vertical motion. NOTE: More slack in the anchor line may improve anchor holding performance, but too much slack may allow the product to flip over in strong winds. For best results, maximize your anchor holding power via more weight or a different type of anchor and minimize your anchor line length.

Mark line by attaching a buoy or other float to the end of your anchor line when not in use. You'll find it easier to identify the location of your anchor.

Anchoring a stainless steel snap hook to the buoy simplifies the process of removing your product from the water for cleaning or repair. It also makes it simple to return your product to its previous location.

DEFLATION

PRIOR TO DEFLATION, REMOVE ALL PEOPLE FROM THE UNIT!

Use one of the Inflator/Deflator devices recommended in the “Inflation” Section for faster deflation.

Completely Dry Unit. Wipe the product off with a terry cloth towel and allow to dry completely. Store for next use. See Storage Section for details.

Halkey Roberts Valve - Unscrew the cap by twisting counterclockwise to expose the air valve stem. Open the air valve by pushing in the stem and rotating clockwise. Allow air to escape. Pushing on the stem and rotating counterclockwise will seal the valve. Replace cap making sure it is tightened securely.

MAINTENANCE

Maintenance is essential to increase the life of your product. Please follow all maintenance and repairs according to this manual. If you are unsure please contact your local dealer, service center or RAVE Sports directly.

- Inspect product regularly for potentially unsafe conditions, particularly after storms, and suspected misuse of product.
- Do not use product if repair is needed!
- Clean product regularly per the Cleaning section of manual.
- Check storage area. Make sure it is rodent free and dry.
- Black rubber portion of Valves and Plugs should be lightly coated with a petroleum based product before storage to prevent drying and cracking.
- When disposing of product, do so in such a manner that no hazardous conditions exist at the time the product is discarded.

Always remove your inflatable from the water when not in use. To extend the life of your inflatable – keep out of sunlight when not in use. For additional protection, we recommend using U.V. protectant.

CLEANING

If your inflatable is used intensively, then it should be cleaned on a weekly basis. It is also important to clean and dry the product before it is packed away.

When cleaning your product never use strong detergents or silicone-based products. Also never use high pressure cleaning equipment such as a “pressure washer”. This will result in damage to your product.

Clean the outside surface only. Clean your inflatable with mild soap and fresh water and check that the valves are clean and not damaged.

RAVE recommends the use of U.V. protectant for prolonging the life of your inflatable. To remove algae and other hazards from the ocean, you can use a special cleaning agent from your local marina. Following the directions carefully.

All hardware (O-rings, springs, and such) should be rinsed with fresh water weekly. Although normal wear and tear is unavoidable, this will increase the life of your product.

STORAGE

When storing your inflatable, keep it in a clean and dry place that is not affected by major variations in temperatures and other damaging factors. You can store your inflatable deflated and rolled up or lightly inflated. Be careful never to stack anything on top of inflatable.

It is recommended that you allow the unit to completely dry before storage.

It is recommended to lubricate the rubber on the valves with a petroleum based product to increase the life of the valve.

Please note: rodents, such as mice, chew on fabric, including inflatable material. As a precaution you can place moth balls or fabric softener sheets around the products during storage to deter them.

REPAIRS

All of the inflatable products include a repair kit. You can easily repair minor punctures and cuts and even anchor plates or handles.

Conditions necessary for a successful repair are:

- Relative humidity less than 65%.
- Temperature Range between 62° - 77° F (16°-25°C).
- Avoid performing repairs in direct sunlight or rain.

Step 1 - Locate the damaged area. The easiest way is to fully inflate the product and listen for the leak, or to spray with soapy water and look for bubbles. Mark the damaged area with a crayon or wax pencil and deflate the product.

Step 2 – Cut out a patch approximately 2 inches (5cm) larger than the leak. Clean the damaged part of the product and patch and allow to dry thoroughly.

TIP – It is a good idea to always use a circle or rectangle patch with rounded corners. Pointed corners tend to pull off.

Step 3 – Next clean the area and the patch with alcohol, grease remover, or fingernail polish remover and allow to dry thoroughly.

Step 4 - Apply glue in a very thin layer to the patch and then to the area of the leak. Let the glue stand until tacky, usually 30 seconds – 1 minute.

TIP – Place glue on the dull side of the patch and to the shiny side of the unit. Then when you apply the patch it will match.

TIP – Use a short brush (just cut the length off) as this digs into the material better to spread the glue. Also try to use a brush with real hair instead of synthetic.

Step 5 – Place the patch over the leak

Step 6 – Press out the air pockets which may have formed under the patch. You can use any round object, such as a spoon, starting in the center and then working outwards toward the edges. You can keep the repair “tight” by clamping together with spring pliers.

Step 7 – Allow repair to cure for 24 hours before re-inflating.

Step 8 – Inflate the repaired product.

TIP – It is a good idea to check again for leaks. If you have multiple leaks, the air will rush out of a larger hole before a smaller one.

CAUTION: When using glue, remove unused glue from threads of tube and cap and carefully replace the cap on the tube. If properly sealed it will keep perfectly.

Do not leave the tube in the sun or next to heat sources or direct flames.

- Check that the room is properly ventilated, avoid inhaling or ingesting the glue and avoid contact with skin.
- For major repairs, take your product to your local dealer or manufacturer.

RAVE
S P O R T S®

RAVE
S P O R T S®

THIS PAGE INTENTIONALLY LEFT BLANK.

RAVE
S P O R T S®

RAVE
S P O R T S®



WWW.RAVESPORTS.COM

RAVE SPORTS

A Revel Match, LLC Company

985 Aldrin Drive #301

Eagan MN, 55121

800.659.0790

June 2017