



We strive to ensure that our products are of the highest quality and free of manufacturing defects or missing parts. However, if you have any problems with your new product,

DO NOT RETURN IT TO THE STORE,

please contact us toll free @:

1-888-996-2729

FAX: 1-866-873-3531

gameroom@escaladesports.com

Mailing Address: (Correspondence Only)

Escalade Sports
PO Box 889
Evansville, Indiana 47706-0889

Physical Location:

Escalade Sports
817 Maxwell Ave.
Evansville, Indiana 47711

Please visit our Web site at:

www.escaladesports.com

Please have your model number when inquiring about parts.

When contacting Escalade Sports please provide your model number, date code (if applicable) and part number if requesting a replacement part. These numbers are located on the product, packaging, and this owners manual.


Your Model Number **G03000**

Date Code **2 - G03000W/F- - SY**

Purchase Date _____

PLEASE RETAIN THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE

**IMPORTANT! READ EACH STEP
IN THIS MANUAL BEFORE YOU
BEGIN THE ASSEMBLY.**



TWO ADULTS ARE REQUIRED TO ASSEMBLE THIS 84" RENEGADE BILLIARD TABLE

Tools Required:

Socket Head Wrench (Included)
Furniture Polish and Soft Cotton Cloth
Carpenters Level

Assembly Tips

Make sure you understand the following tips before you begin to assemble your billiard table.


1. Start all bolts by hand before tightening.
2. Some drawings or images in this manual may not look exactly like your product. Please read and understand the text before starting each assembly step.




ATTENTION:

**READ AND FOLLOW ALL ASSEMBLY, OPERATION, AND
SAFETY INSTRUCTIONS CAREFULLY. AT LEAST TWO
ADULTS ARE REQUIRED TO ASSEMBLE THIS GAME TABLE.**


HARDWARE IDENTIFIER (To Scale)




H1 - 8mm x 130mm Hex Head Bolt
(8 pcs)



(Not to Scale)
T1 - Socket Head Wrench
(1 pc)




H2 - 8mm x 55mm
Hex Head Bolt
(12 pcs)



H3 - M8 Flat Washer
(24 pcs)




H4 - M8 Lock Washer
(24 pcs)




H5 - 8mm x 30mm
Hex Head Bolt
(4 pcs)


PARTS IDENTIFIER (Not to Scale)




P1 - Main Cabinet
(1 pc)




P2 - End Leg Cross Support
(2 pcs)



P3 - Right Leg
(2 pcs)




**P4 -Left Leg
(2 pcs)**



**P5 - Long Middle Metal Leg Support
(1 pc)**




**P6 -Leg Leveler
(4 pcs)**




**P7 - Triangle Leg Support Angle Block
(8 pcs)**


ACCESSORIES IDENTIFIER (Not to Scale)



**A1 - Billiard Ball Set
(1 pc)**




**A2 -Pool Cue
(2 pcs)**



**A3 - Triangle
(1 pc)**



**A4 - Cue Chalk
(2 pcs)**



**A5 - Playfield Brush
(1 pc)**

PARTS REQUIRED

1pc - **P1** Main Cabinet

2pcs - **P3** Right Leg

2pcs - **P4** Left Leg

8pcs - **P7** Triangle Leg Support Angle Blocks

12pcs - **H2** Hex Head Bolt

12pcs - **H3** Flat Washer

12pcs - **H4** Lock Washer


NOTE: Please inspect all Bolt holes to insure they are clean and open.

STEP 1

Note: To best protect the table, build this game table in the carton bottom tray it was packed in.

Attach the **P3** Right Legs and **P4** Left Legs onto the **P1** Main Cabinet using **P7** Triangle Leg Support Angle Blocks and the **H2** Hex Head Bolts, **H4** Lock Washers and **H3** Flat Washers as shown in **FIGURE 1**.

Do not tighten the H2 bolts at this time.



PARTS REQUIRED

2pcs - **P2** End Leg Cross Support

8pcs - **H1** Hex Head Bolt


8pcs - **H4** Lock Washer

8pcs - **H3** Flat Washer

STEP 2

Attach the **P2** End Leg Cross Supports onto the Legs using the **H1** Hex Head Bolts, **H4** Lock Washers and **H3** Flat Washers as shown in **FIGURE 2**.

Do not tighten the H1 bolts at this time.



PARTS REQUIRED

1pc - **P5** Long Middle Metal Leg Support
4pcs - **P6** Leg Leveler


4pcs - **H5** Hex Head Bolt
4pcs - **H3** Flat Washer
4pcs - **H4** Lock Washer

STEP 3

Attach the **P5** Long Middle Metal Leg Support onto the **P2** End Leg Cross Supports using the **H5** Hex Head Bolts, **H4** Lock Washers and **H3** Flat Washers as shown in **FIGURE 3**.

Tighten all bolts from STEP 1, 2 & 3 now using the T1 Socket Head Wrench-tight.

Thread the **P6** Leg levelers into legs as shown in **FIGURE 3**.




WARNING:

THIS STEP REQUIRES FOUR OR MORE ADULTS.

WHILE FLIPPING THE TABLE OVER, DO NOT ALLOW TABLE TO REST ON THE SIDE OF LEGS AS THIS COULD DAMAGE THEM.

VERY CAREFULLY TURN THE TABLE OVER AND SET IT ON ITS LEGS. BE CAREFUL. THE TABLE IS VERY HEAVY.



Congratulations! You have now assembled your game table. Please note the Care and Use instructions below to insure many years of trouble free use of your game table.

CARE AND USE OF YOUR TABLE

1. Use spray furniture polish to clean all exterior surfaces of your table.
2. Use the table brush provided to clean the cloth on the table.
3. This product is intended for **INDOOR** use only.
4. **DO NOT** sit, climb or lean on the table.
5. **DO NOT** drag the table when moving it. This will damage the legs.
6. **DO NOT** set drinks on the table.
7. The purchase of a table cover will both protect and help keep clean the entire top of the table.
8. Use a carpenter's level to properly level the table using the Leg Levelers.

PRODUCT PARTS LIST FOR MODEL # G03000

Key #	Part #	Description	Qty.
H1	G03000SYH1	8mm x 130mm Hex Head Bolt	8
H2	G03000SYH2	8mm x 55mm Hex Head Bolt	12
H3	G03000SYH3	M8 Flat Washer	24
H4	G03000SYH4	M8 Lock Washer	24
H5	G03000SYH5	8mm x 30mm Hex Head Bolt	4
T1	G03000SYT1	Socket Head Wrench	1
P1	G03000SYP1	Main Cabinet	1
P2	G03000SYP2	End Leg Cross Support	2
P3	G03000SYP3	Right Leg	2
P4	G03000SYP4	Left Leg	2
P5	G03000SYP5	Long Middle Metal Leg Support	1
P6	G03000SYP6	Leg Leveler	4
P7	G03000SYP7	Triangle Leg Support Angle Block	8
A1	G03000SYA1	Billiard Ball Set	1
A2	G03000SYA2	Pool Cue	2
A3	G03000SYA3	Triangle	1
A4	G03000SYA4	Cue Chalk	2
A5	G03000SYA5	Playfield Brush	1
C1	G03000SYC1	Middle Pocket (pre-installed)	2
C2	G03000SYC2	End Pocket (pre-installed)	4
K1	G03000SYK1	Hardware Kit	1
M1	G03000SYM1	Owner's Manual	1

90 DAY LIMITED WARRANTY

This customer warranty extends to the original owner, on the purchase of any ESCALADE SPORTS Product (hereinafter referred as the "Product").

WARRANTY DURATION: This Product is warranted to the original owner, for a period of 90 days from the original purchase.

WARRANTY COVERAGE: ESCALADE SPORTS warrants to the original owner, this product to be free from defects in material and workmanship when used for the intended purpose under normal use and conditions. THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN DAMAGED BY ACCIDENT, UNREASONABLE USE, NEGLIGENCE, IMPROPER SERVICE, FAILURE TO FOLLOW INSTRUCTIONS PROVIDED WITH THE PRODUCT OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIAL AND WORKMANSHIP.

WARRANTY REPLACEMENT: During the above 90 day warranty period, ESCALADE SPORTS shall provide replacement components or replace with a comparable product at our choosing. If product is defective under normal use and proper care, please contact our Customer Service Dept.

1-888-996-2729 / Customer Service Dept.

Or Write us at:

Escalade® Sports, Inc. - P.O. Box 889, Evansville, IN 47706

Attn: Customer Service Dept.

Or E-mail us at:

customerservice@escaladesports.com

Other than shipping requirements no charge will be made for such replacement of in-warranty Products.

WARRANTY DISCLAIMERS: ANY IMPLIED WARRANTIES ARISING OUT OF THIS SALE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE ABOVE 90 DAY PERIOD. ESCALADE SPORTS SHALL NOT BE LIABLE FOR LOSS OF USE OF THE PRODUCT OR OTHER CONSEQUENTIAL OR INCIDENTAL COSTS, EXPENSES OR DAMAGES INCURRED BY THE CONSUMER OF ANY OTHER USE.

Some states do not allow the exclusion or limitation of implied warranties or consequential or incidental damages, so the above limitations or exclusions may not apply to you.

LEGAL REMEDIES: This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.