



OFFICIALLY LICENSED
CORNHOLE BOARDS



PLEASE KEEP THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE

If you have any concerns with your product please visit our website www.escaladesports.com for fastest service. Please have a copy of your receipt of purchase. For any technical support or warranty issues please contact Escalade® Sports at 1-800-426-1421 or e-mail us at customerservice@escaladesports.com



LIMITED 90-DAY ESCALADE SPORTS WARRANTY

All Escalade® Sports games have a limited 90-day from date of purchase warranty. This warrants the retail purchaser for any Escalade Sports game purchased to be free from any defect in materials and construction for 90 days from the date of purchase. The only exceptions to the warranty include main frames, tabletops, playing surfaces, batteries or tools. Damaged main frames, tabletops, playing surfaces need to be returned to the store as we are unable to replace these parts. Normal play wear and usage is not covered under the warranty, nor is wear or damage due to improper use of the Escalade Sports game. This will void any and all Escalade Sports warranties.

A PURCHASE RECEIPT (or other proof of purchase date) will be required before any warranty service is initiated. All requests for warranty service can be submitted by submitting a claim here <https://www.escaladesports.com/pages/warranties-registrations>, by email at customerservice@escaladesports.com, or by contacting our Customer Service Department at 1-800-467-1421.

IMPORTANT NOTICE! Please contact us before returning the product to the store.

WARNINGS




WARNING: Not for use by children without adult supervision.

This is not a child's toy. Adult supervision is required for children playing this game. Please read instructions carefully.

PARTS LIST

2 Game Platforms



BAGS NOT INCLUDED
PLAYS BEST WITH **FCL** STAMPED BAGS

PLAYING INSTRUCTIONS



PLAYING AREA

Select an open area that allows for 27 ft. between the two foul lines (front of the cornhole boards).

TEAMS

Play is between two players or two teams. One member from each team will stand next to each board.

RULES OF THE GAME

- For the first round, decide Player 1 and/or Team 1 by tossing a coin, or some other suitable method. For following rounds, the team scoring the highest points in the previous round is the first to toss in the next round.
- Each round consists of one person (either Player 1 or Player 1/Team 1) tossing cornhole bags. Play continues alternating Player/Team until each player has tossed their bags.
- Cornhole bags may be tossed in any way the player chooses, as long as they are tossed individually.
- Players must not step across the foul line (front edge of the cornhole board) during a throw, or that throw does not count.
- Point Values are as follows: A bag thrown through the hole earns 3 points. A bag that lands on the board earns 1 point. Subtract the low score from the high score for each round of play. For example: Team A has 1 bag in the hole and 2 bags on the board, for a score of 5 points. Team B has two bags on the board, for a score of 2 points. Team A (5 points) – Team B (2 points) = Team A (3 points). Team A receives 3 points for that round of play.
- No Score - Cornhole bags that touch the ground first will not be scored.
- To Win – First Player/Team to reach 21 points wins!
- Hint: You can knock your opponent's cornhole bags off the board.



See for yourself why the ACL is the only name
you need to know when it comes to cornhole.

ANYONE CAN PLAY, ANYONE CAN WIN



ESCALADE® SPORTS

817 Maxwell Avenue, Evansville, IN 47711
1.800.467.1421 • www.escaladesports.com

©2023 Escalade® Sports all rights reserved