

Homedics

bubblemate footspa



✓ Register your product today at
www.homedics.co.uk/product-registration

3 YEAR GUARANTEE

FB-55PB-GB

PRODUCT FEATURES:



INSTRUCTIONS FOR USE:

1. Ensure that the unit is unplugged before filling with water. Fill with warm water to the MAX fill line located on the inside of the tub.
2. **CAUTION: DO NOT FILL WATER OVER THE MAX FILL LINE**
NOTE: The foot spa will not heat cold water. For a warm water massage, fill the unit with warm water.
3. Place the unit on the floor in front of a chair. It is recommended to place the product on a towel.
4. Plug the unit into a 220-240 AC power supply.
5. Sit down and place your feet in the spa.
6. To operate the unit, press the power button on the top of the product.
7. Enjoy a deep massage by sliding feet back and forth over the stimulating raised massage nodes on the footspa floor.
8. To turn off, press the button again to deactivate.
9. To empty: First, unplug the unit. Tip the unit, allowing water to pour out along the rear corner of the footbath. **DO NOT** pour water over the power button.
NOTE: DO NOT hold or carry the unit by the removeable splash guard.

Storage

Place the appliance in its box or in a safe, dry, cool place. **DO NOT** wrap the power cord around the appliance. **DO NOT** hang the unit by the cord.

MAINTENANCE:

Cleaning

- Unplug the appliance and allow to cool before cleaning. Clean only with a soft, slightly damp sponge.
- Do not immerse in any liquid to clean.
- Never use abrasive cleaners, brushes, glass / furniture polish, paint thinner etc to clean.
- Periodically straighten cord if it becomes twisted.

PLUG: If the plug on this appliance is damaged, it can be replaced with a BS 1363 plug, fitted with a 3A BS 1362 fuse. The recommended fuse for this appliance is 3 amp. Care must be taken when changing the plug. If in doubt, contact a qualified electrician.

