

3.938 in

5.989 in

12.010 in

6.021 in

4.000 in

PRODUCTION DIE

Screw-Feed Tubing Cutter

Coupe-tube à vis
Cortatubos alimentado por tornillo

INSTRUCTIONS

- Insert tubing. Tighten knob firmly.
- Rotate cutter forward with continuous even pressure.
- Tighten knob at each complete turn. Do not force.
- Repeat until tubing is completely cut.
- Use attached reamer for rough edges.

INSTRUCCIONES

- Inserte el tubo. Apriete el tornillo de ajuste.
- Ruede el cortatubos avanzándolo en un movimiento continuo con presión uniforme.
- Apriete el tornillo de ajuste a cada vuelta. No lo fuerce.
- Repite los pasos anteriores hasta que se corte completamente el tubo.
- Use el escarador para bordes ásperos.

WARNING: Cancer and Reproductive Harm -- www.P65Warnings.ca.gov

AVERTISSEMENT: Peut causer le cancer et une malfonction des organes de la reproduction -- www.P65Warnings.ca.gov

ADVERTENCIA: Cáncer y daño al sistema reproductivo -- www.P65Warnings.ca.gov

Superior Tool
Naperville, IL 60563
superiortool.com
© 2023 Superior Tool Company

MADE IN USA
Fabriqué aux États-Unis
Hecho en EE.UU.
23018-10/23

35236
0 17 197 35236 2

Superior Tool

35236
MADE IN USA

CUTTING CAPACITY
1/8" to 1-1/8" O.D.

ALUMINUM BRASS COPPER™

SXT SUPERIOR X-TRA TOUGH WHEEL™

LIFETIME WARRANTY

Replacement wheel #42835
Roue de rechange #42835

QR Code