






Portable Flipchart Easel 30227




Item	Description/Quantity
A.	Easel Assembly (1)
B.	Thumb Knob (2)
C.	Dry Erase Surface (1)



1 Dry Erase Sheet Mount



3 Extend Legs



Iceberg Enterprises
www.icebergenterprises.com

2 Attach Pad Knobs

