amalfi

ASSEMBLY INSTRUCTIONS


OWEN CONSOLE TABLE

ITEM NO: G0001089


PARTS




A X 16




B



C X 4




D




E


STEP 1




STEP 2



FINAL



WARNING



Children have died from furniture tipover.

- ALWAYS secure it with an anchor device
- NEVER allow children to stand, climb or hang on drawers, doors or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



This furmiture type is at high risk of toppling over.

Ask staff for more information or visit https://www.productsafety.gov.au