
# LED Mirror

## INSTALLATION INSTRUCTIONS



## PRIOR TO INSTALLATION:

- Inspect product to ensure no damages have occurred while in shipping.
- Observe all plumbing and building codes in accordance with your state and local requirements.
- All dimensions are nominal! Be sure to measure your mirror prior to installation.
- The step-by-step guidelines in the installation instructions are a general reference. Should there be any discrepancies, Swiss Madison cannot be held liable. It is recommended to install all Swiss Madison products by hiring a licensed professional.
- Read installation and maintenance instructions thoroughly before installing. Be sure to use proper tools and always wear proper personal safety accessories for your protection.


### QUESTIONS OR CONCERNS?

Please contact us:


1-434-623-4766

info@swissmadison.com


## INCLUDED PARTS:



Vanity Mirror



Plastic Anchors



Screws



Mirror Bracket

## SUGGESTED TOOLS:



Safety Glasses




Hammer




Screwdriver




Drill



Level



Box Cutter



Tape Measure




Pencil

## Important Safety & Installation Instructions

When using electrical appliances, safety is the top priority—especially in homes with children. Please read all instructions before use to ensure you stay safe.


- This product is for indoor use only.
- **Turn off the power:** Before installing or maintaining this product, ensure the power is completely turned off at the consumer unit or fuse board.
- **Wear protective gear:** To prevent personal injury or damage to the product during installation, please wear appropriate protective equipment.
- **Cleaning care:** Do not use acidic, alkaline, or alcohol-based cleaners on the mirror. Always use a soft cloth to clean it.
- **Check the wall:** Before installing, ensure there are no hidden obstacles—such as electrical wires or water pipes—inside the wall.
- This product is designed to hang in one specific direction. Installing the unit in the wrong orientation will cause the touch controls and anti-fog features to malfunction.




## INSTALLATION:


### 1 Hanging Bracket Installation

- Mark pilot holes on the wall using the pre-drilled holes on the mounting bracket as a guide. Use a level to ensure the bracket is aligned properly.
- Always check for studs before drilling – mount into studs where possible. When studs are not available, use included plastic anchors . Fix the bracket to the wall.
- Mounting height standard guidance: Mirror center at 60" to 64" from finished floor. Center horizontally over vanity. Leave 4" to 6" above faucet/backsplash.




## 2 Connect & Hang the Mirror


- Make sure power to the hardwiring is completely off.
- Before touching the wires, test the junction box with a non-contact voltage tester to confirm power is truly OFF. Breaker labeling is often incorrect.
- Proceed to connect the mirror power lines. Connect wires as follows:
  BLACK (or RED) = HOT (live); WHITE = NEUTRAL; GREEN (or bare) = GROUND
  Twist matching wire pairs together. Secure with wire nuts (not included – buy separately).
  Wrap each connection with electrical tape. No bare wire should remain exposed.
- Hang the mirror to the bracket. Two people are required as mirror is heavy and awkward to hang alone.
  Person 1: Hold and guide thye mirror onto the bracket.
  Person2: Confirm wires are clear and mirror is seated flush.




**TIP**: If the junction box is not centered behind the mirror, use a cord cover or wall plate to conceal exposed cable runs.

## FEATURE FUNCTIONS:





- Short press button to turn on the light.
- When the light is on, long press button to adjust brightness.
- Short press button to turn off the light.



- Short press button to activate the anti-fog function.
- Short press the button again to turn off the anti-fog function.

# ONE-YEAR LIMITED WARRANTY

Swiss Madison® products are made with quality materials and excellent craftsmanship to provide our customers with beautiful, durable, long-lasting products. Should there be any defects in materials or craftsmanship under regular use that are discovered within the first year after delivery, Swiss Madison® will provide replacement parts at no charge, or at its discretion, replace any product or part of the product that is deemed defective, under normal installation, use, service or maintenance. This warranty applies only to the original purchaser. Proof of purchase must be submitted with any warranty claim.

Swiss Madison® recommends that all installations of Swiss Madison® products to be conducted by a licensed plumber or contractor. Swiss Madison® will not be held responsible for any damage or product failure due to improper installation, misuse, or failure to utilize a licensed plumber or contractor for installation. Swiss Madison® is not responsible for any installation or removal costs.

**THIS ONE-YEAR LIMITED WARRANTY WILL BE VOIDED IF:**

- The installation instructions were not followed by the installer
- The product has been moved from its initial place of installation
- The product has in any way been modified from its original condition
- The product has been subjected to improper maintenance, abuse, misuse, excessive use of chemicals, accidents, or other damages

Swiss Madison® makes no warranty that its products comply with any local building or plumbing codes. It is the consumer's responsibility and obligation to determine local code compliance prior to and during installation.

Swiss Madison® is not responsible for any special, incidental or consequential damages associated with the installation, replacement, return or use of the original purchaser's product. This includes, but is not limited to: freight costs, labor, travel time, lost profit, home damages and other contingent liabilities and costs (including, without limitation, costs associated with 'professionals' or 'experts', investigations, audits, analyses, attorneys and any other professional/hired services). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

The Swiss Madison® warranty is a comprehensive and explicit limit of liability. All other warranties are hereby disclaimed and waived.

**QUESTIONS OR CONCERNS?** Please contact us directly at: 1-434-MADISON (623-4766)

**WARNING:**
Contents of your order may contain sharp and possibly other harmful pieces and may cause hazard to children and adults. Swiss Madison® is not responsible in any way for personal injuries or damages.