



Specially formulated spray buff compound which gives your floors a durable, high gloss quickly and easily. Plus, Hil-Glo cleans the surface of your floor as it polishes. It delivers maximum gloss while it cleans stubborn scuffs and black heel marks.

Features & Benefits

- Gives your floor a durable, high gloss quickly and easily
- Cleans the surface of the floor as it polishes
- Provides resistance to black heel marks, scuffs, and scratching to keep floors looking great

Item Number & Unit of Measure

Item Number	HIL9953306
Unit of Measure	1 gal Bottle

Specifications

Color	Pale Yellow
Appearance	Translucent
Fragrance	Citrus
Formula Type	Liquid
Dilution Ratio	RTU
PH	8.00 - 9.00
Non-Volatile Matter	2.00 - 3.00%

Safety

See safety datasheet (if applicable) and product label for safety information, handling and proper use.

Directions for Use

PREPARATION: For best results when using a spray buff program, a good base coat of seal and finish is necessary. If the floor is extremely dirty, with a heavy finish buildup, it should be stripped and thoroughly rinsed. Apply seal and finish per label directions. If the floor does not need to be stripped, but the base needs to be re-established, scrub the floor with a blue or green pad and the recommended cleaner, rinse, and apply one or two coats of finish. HIL-GLO may be used with either low or high speed floor machines. Dust mop then spot mop, damp mop, or auto-scrub the floor before spray buffing.

APPLICATION: HIL-GLO is best applied with a pump-up sprayer or spray bottle. DO NOT MOP ON THE FLOOR. Simply shake the product, pour into a sprayer and apply a light mist. Do not allow product to dry before buffing. Using a standard 175-600 rpm machine, immediately buff the sprayed area with a red pad until it is dry. Turn and change pad frequently to avoid buildup in the pad. Follow with a white pad to increase gloss. For 1000-1500 rpm machines, apply HIL-GLO to 4 ft. by 60 ft. area and immediately buff the sprayed area with a high-speed beige buffer pad. Always dust mop the floor after buffing. (Asbestos flooring must be properly sealed and finished before using a buffer. Do not use abrasive pads on tile containing asbestos.)

NOTICE: Keep container closed when not in use. Do not pour unused product back into container. Best results are obtained with adequate ventilation and floor temperatures above 60°F (16°C).