





ITEM NAME/NOM D'ITEM: FREYCINET DINING CHAIR
ITEM #/NO. ITEM:703987

PARTS LIST/LISTE DES PIÈCES


(1)	(2)	(3)	(4)
 X1	 X1	 X1	A  X3 M6x35mm B  X3 M6x18mm C  X1 M4

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE


I



II



III



For missing parts or damaged parts, please call /
Pour pièce manquante ou endommagée, veuillez appeler: USA, Canada and Mexico: (866)-798-6663