



We strive to ensure that our products are of the highest quality and free of manufacturing defects or missing parts. However, if you have any problems with your new product,

DO NOT RETURN IT TO THE STORE,

please contact us toll free @:

1-888-996-2729

FAX: 1-866-873-3531

gameroom@escaladesports.com

Mailing Address: (Correspondence Only)

Escalade Sports
PO Box 889
Evansville, Indiana 47706-0889

Physical Location:

Escalade Sports
817 Maxwell Ave.
Evansville, Indiana 47711

Please visit our Web site at:

www.escaladesports.com

Please have your model number when inquiring about parts.

When contacting Escalade Sports please provide your model number, date code (if applicable) and part number if requesting a replacement part. These numbers are located on the product, packaging, and this owners manual.


Your Model Number AL3250

Date Code 2 - AL3250F- - SY

Purchase Date _____

PLEASE RETAIN THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE

**IMPORTANT! READ EACH STEP
IN THIS MANUAL BEFORE YOU
BEGIN THE ASSEMBLY.**



TWO ADULTS ARE REQUIRED TO ASSEMBLE THIS AUSTIN 84" POOL TABLE

Tools Required:

Socket Head Wrench (Included)
Furniture Polish and Soft Cloth
Carpenters Level

An electric screwdriver is helpful in assembly. However, please set at low torque and use extreme caution with an electric screwdriver because you could overtighten the hardware and strip the screws.

Assembly Tips

Make sure you understand the following tips before you begin to assemble your billiard table.


1. Start all bolts by hand before tightening.
2. Some drawings or images in this manual may not look exactly like your product. Please read and understand the text before starting each assembly step.



ATTENTION:

**READ AND FOLLOW ALL ASSEMBLY, OPERATION, AND
SAFETY INSTRUCTIONS CAREFULLY. AT LEAST TWO
ADULTS ARE REQUIRED TO ASSEMBLE THIS GAME TABLE.**


HARDWARE IDENTIFIER (To Scale)




H1 - 8mm x 130mm Hex Head Bolt
(8 pcs)




(Not to Scale)
T1 - Socket Head Wrench
(1 pc)




H2 - 8mm x 55mm
Hex Head Bolt
(12 pcs)



H3 - M8 Flat Washer
(24 pcs)



H4 - M8 Lock Washer
(24 pcs)




H5 - 8mm x 30mm
Hex Head Bolt
(4 pcs)




H6 - 3.5mm x 35mm
Phillips Flat Head Screw
(14 pcs)

PARTS IDENTIFIER (Not to Scale)



P1 - Main Cabinet
(1 pc)



P2 - End Leg Block
(2 pcs)




P3 - Right Leg
(2 pcs)




P4 - Left Leg
(2 pcs)



P5 - End Block
(2 pc)




P6 - Top Panel of Lower
Center Support Beam
(1 pc)



P7 - Side Panel of Lower
Center Support Beam
(2 pcs)




P8 - Leg Leveler
(4 pcs)




P9 - Triangle Leg Support Blocks
(8 pcs)


ACCESSORIES IDENTIFIER (Not to Scale)



A1 - Billiard Ball Set
(1 pc)




A2 -Pool Cue
(2 pcs)



A3 - Triangle
(1 pc)



A4 - Cue Chalk
(2 pcs)



A5 - Playfield Brush
(1 pc)

PARTS REQUIRED

1pc - **P1** Main Cabinet
 2pcs - **P3** Right Leg
 2pcs - **P4** Left Leg
 8pcs - **P9** Triangle Leg Support Block

12pcs - **H2** Hex Head Bolt
 12pcs - **H3** Flat Washer
 12pcs - **H4** Lock Washer

NOTE: Please inspect all Bolt holes to insure they are clean and open.
 To best protect table, build this game table in the carton bottom tray it was packed in.

STEP 1

Attach the **P3** Right Legs and **P4** Left Legs **P9** Triangle Leg Support Blocks onto the **P1** Main Cabinet using the **H2** Hex Head Bolts, **H3** Flat Washers and **H4** Lock Washers as shown in **FIGURE 1**.

Do not tighten the H2 bolts at this time.




FIGURE 1

PARTS REQUIRED

2pcs - **P2** End Leg Block
 8pcs - **H1** Hex Head Bolt

8pcs - **H3** Flat Washer
 8pcs - **H4** Lock Washer

STEP 2

Attach the **P2** End Leg Blocks onto the **P3/P4** Legs using the **H1** Hex Head Bolts, **H3** Flat Washers and **H4** Lock Washers as shown in **FIGURE 2**.

Do not tighten H1 Bolts at this time.




FIGURE 2

PARTS REQUIRED

1pc - **P6** Top Panel of Lower Center Support Beam
2pcs - **P7** Side Panel of Lower Center Support Beam


2pcs - **P5** End Block
14pcs - **H6** Phillips Flat Head Screw

STEP 3

Attach the **P6** Top Panel and **P5** End Blocks onto the **P7** Side Panels using the pilot holes and **H6** Phillips Flat Head Screws as shown in **FIGURE 3**.

DO NOT strip out **H6** screws.

FIGURE 3



PARTS REQUIRED

4pcs - **P8** Leg Leveler
4pcs - **H3** Flat Washer

4pcs - **H4** Lock Washer
4pcs - **H5** Hex Head Bolt


STEP 4

Attach the **STEP 3** Center Support Beam Assembly onto the **P2** End Leg Blocks using the **H5** Hex Head Bolts, **H3** Flat Washers and **H4** Lock Washers as shown in **FIGURE 4**.

Tighten all H1, H2 from STEP 1 & 2 and H5 Bolts using T1 Socket Head Wrench at this time--- DO NOT overtighten.

Thread **P8** Leg levelers into legs as shown in **FIGURE 4**.

FIGURE 4



WARNING:

THIS STEP REQUIRES FOUR OR MORE ADULTS.
VERY CAREFULLY TURN THE TABLE OVER AND SET IT ON ITS LEGS. BE CAREFUL. THE TABLE IS VERY HEAVY.

Congratulations! You have now assembled your game table. Please note the Care and Use instructions below to insure many years of trouble free use of your game table.

CARE AND USE OF YOUR TABLE

1. Use spray furniture polish to clean all exterior surfaces of your table.
2. Use the table brush provided to clean the cloth on the table.
3. This product is intended for **INDOOR** use only.
4. **DO NOT** sit, climb or lean on the table.
5. **DO NOT** drag the table when moving it. This will damage the legs.
6. **DO NOT** set drinks on the table.
7. The purchase of a table cover will both protect and help keep clean the entire top of the table.
8. Use a carpenter's level to properly level the table using the Leg Levelers.

PRODUCT PARTS LIST FOR MODEL # AL3250

Key #	Part #	Description	Qty.
H1	AL3250SYH1	8mm x 130mm Hex Head Bolt	8
H2	AL3250SYH2	8mm x 55mm Hex Head Bolt	12
H3	AL3250SYH3	M8 Flat Washer	24
H4	AL3250SYH4	M8 Lock Washer	24
H5	AL3250SYH5	8mm x 30mm Hex Head Bolt	4
H6	AL3250SYH6	3.5mm x 35mm Phillips Flat Head Screw	14
T1	AL3250SYT1	Socket Head Wrench	1
P1	AL3250SYP1	Main Cabinet	1
P2	AL3250SYP2	End Leg Block	2
P3	AL3250SYP3	Right Leg	2
P4	AL3250SYP4	Left Leg	2
P5	AL3250SYP5	End Block	2
P6	AL3250SYP6	Top Panel of Lower Center Support Beam	1
P7	AL3250SYP7	Side Panel of Lower Center Support Beam	2
P8	AL3250SYP8	Leg Leveler	4
P9	AL3250SYP9	Triangle Leg Support Block	8
A1	AL3250SYA1	Billiard Ball Set	1
A2	AL3250SYA2	Pool Cue	2
A3	AL3250SYA3	Triangle	1
A4	AL3250SYA4	Cue Chalk	2
A5	AL3250SYA5	Playfield Brush	1
K1	AL3250SYK1	Hardware Kit	1
M1	AL3250SYM1	Instruction Manual	1

90 DAY LIMITED WARRANTY

This customer warranty extends to the original owner, on the purchase of any ESCALADE SPORTS Product (hereinafter referred as the "Product").

WARRANTY DURATION: This Product is warranted to the original owner, for a period of 90 days from the original purchase.

WARRANTY COVERAGE: ESCALADE SPORTS warrants to the original owner, this product to be free from defects in material and workmanship when used for the intended purpose under normal use and conditions. THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN DAMAGED BY ACCIDENT, UNREASONABLE USE, NEGLIGENCE, IMPROPER SERVICE, FAILURE TO FOLLOW INSTRUCTIONS PROVIDED WITH THE PRODUCT OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIAL AND WORKMANSHIP.

WARRANTY REPLACEMENT: During the above 90 day warranty period, ESCALADE SPORTS shall provide replacement components or replace with a comparable product at our choosing. If product is defective under normal use and proper care, please contact our Customer Service Dept.

1-888-996-2729 / Customer Service Dept.

Or Write us at:

Escalade® Sports, Inc. - P.O. Box 889, Evansville, IN 47706

Attn: Customer Service Dept.

Or E-mail us at:

customerservice@escaladesports.com

Other than shipping requirements no charge will be made for such replacement of in-warranty Products.

WARRANTY DISCLAIMERS: ANY IMPLIED WARRANTIES ARISING OUT OF THIS SALE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE ABOVE 90 DAY PERIOD. ESCALADE SPORTS SHALL NOT BE LIABLE FOR LOSS OF USE OF THE PRODUCT OR OTHER CONSEQUENTIAL OR INCIDENTAL COSTS, EXPENSES OR DAMAGES INCURRED BY THE CONSUMER OF ANY OTHER USE.

Some states do not allow the exclusion or limitation of implied warranties or consequential or incidental damages, so the above limitations or exclusions may not apply to you.

LEGAL REMEDIES: This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.