









ASSEMBLY INSTRUCTION


END TABLE

| | | | |
|---|---|--|---|
| A Top Panel | B Leg | C Bolt Ø1/4"x70mm | D Flat Washer Ø1/4"xØ16x1.5mm |
|  |  |  |  |
| 1pc | 3pcs | 6pcs | 6pcs |
| E Lock Washer Ø1/4"xØ10x1.5mm | F Levelers Ø1/4"xØ19x15mm | G Allen Key M4 | |
|  |  |  | |
| 6pcs | 3pcs | 1pc | |




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

-
- 1** Attach the Leg (B) to Top Panel (A) using Bolt (C), Lock Washer (E), Flat Washer (D) by Allen Key (G).



-
- 2** Assemble Levelers (F) to Leg (B).
Remark: If there is any gap between the legs and ground, please adjust the levelers until it reaches the ground.











Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

ASSEMBLY INSTRUCTION


COFFEE TABLE

| | | | |
|---|---|--|---|
| A Top Panel | B Leg | C Bolt Ø1/4"x70mm | D Flat Washer Ø1/4"xØ16x1.5mm |
|  |  |  |  |
| 1pc | 4pcs | 8pcs | 8pcs |
| E Lock Washer Ø1/4"xØ10x1.5mm | F Levelers Ø1/4"xØ19x15mm | G Allen Key M4 | |
|  |  |  | |
| 8pcs | 4pcs | 1pc | |




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

-
- 1** Attach the Leg (B) to Top Panel (A) using Bolt (C), Lock Washer (E), Flat Washer (D) by Allen Key (G).



-
- 2** Assemble Levelers (F) to Leg (B).
Remark: If there is any gap between the legs and ground, please adjust the levelers until it reaches the ground.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.