



2-in-1 Pompom Maker







2-in-1 Pompom Maker

To make a pompom
you will need:

- 2-in-1 pompom maker
- Yarn (see chart for approximate quantities)
- Scissors
- Crochet Hook



			
Tangerine/Mandarine	1.5" (3,5 cm)	>	.28 oz (8 g)
Red/Rouge	2" (5 cm)	>	.56 oz (16 g)
Pool Blue/Bleu Piscine	3" (7 cm)	>	1.59 oz (45 g)
Apple/Pomme	3.5" (9 cm)	>	2.50 oz (70 g)



2-in-1 Pompom Maker



1. To open pompom maker, push both right arms (1) away from you while holding left arms (2) firmly. This will open the lock and allows the arms to swing open.



2. To change pompom maker size, lift disc off center peg and pull to remove. Insert the desired size by placing the bottom corner of disc in the tool and rotating into place. Be sure to secure the disc on the center peg.



2-in-1 Pompom Maker



3. Evenly wrap one half of pompom maker with yarn. Do not cover the tool or lock. Use 2 strands of yarn for faster wrapping.



4. Wrap pompom maker half until it is completely full.



5. Cut the yarn end and secure by pulling it under some of the wrapped yarn with a crochet hook.



6. Fully wrap other side and close pompom maker.



2-in-1 Pompom Maker




7. Cut wrapped yarn between discs. Do not open pompom maker.



8. Cut a long piece of yarn and double. Thread yarn piece through hole inside of tool and between discs.



9. Tie yarn tightly with a double knot.



10. Open pompom maker and remove pompom.



2-in-1 Pompom Maker

Time to Trim!



11. First, make a rough cut by trimming around the middle.



12. Next, trim all sides of pompom evenly.



13. Finally, remove any remaining unevenness to create the perfect pompom.



14. Finished!