



# Assembly Instruction

ITEM NO.: 1047RN-1






ACCENT CHAIR




**Legs are stored at the bottom of seat, please take out the legs for assembly.**

**Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to spliting or cracking the wood.**


## Component list

No	Drawing	Qty	Description
A		1	BACK REST
B		1	SEAT
C		1	BOLT
D		4	WOODEN LEG
E		4	PLASTIC WASHER (ø1.89")


### Step #1



### Step #2



### Step #3



## Care Instruction for Velvet Furniture:

In order to maintain the original appearance of your Velvet Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Velvet.
- Vacuum or wipe with a soft cloth to remove dust.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.