
Hardware™ Resources

Shoe Fence Drilling Jig (SF17, SF23, SF29)

IMPORTANT: Print at 100% actual size. Do not scale or fit to page.

SF17
For 18" Shelf




1 inch

INSTRUCTIONS:

1. Print at 100% actual size on standard letter (8.5" x 11") sheet.
   Do not use scale or fit to page options in the print dialog box.
   Check that printed sheet is sized properly using a ruler and the 1 inch marker to the right.
2. Cut out jig for your shelf size.
3. Align Left edge flush to wall. Align Bottom edge flush to shelf front edge, creating 1/2" setback from front edge.
4. Drill 5mm holes through marked circles.
5. Flip jig and align Right edge flush to wall, keeping Bottom edge flush to shelf front.
6. Drill remaining holes.


SF29
For 30" Shelf



Align dotted lines on both top and bottom cutouts and tape together to connect both sides for full SF29 template

Align dotted lines on both top and bottom cutouts and tape together to connect both sides for full SF29 template

SF29
For 30" Shelf



Hardware™ Resources

Shoe Fence Drilling Jig (SF17, SF23, SF29)

IMPORTANT: Print at 100% actual size. Do not scale or fit to page.

1 inch

INSTRUCTIONS:

1. Print at 100% actual size on standard letter (8.5" x 11") sheet. Do not use scale or fit to page options in the print dialog box. Check that printed sheet is sized properly using a ruler and the 1 inch marker to the right.
2. Cut out jig for your shelf size.
3. Align Left edge flush to wall. Align Bottom edge flush to shelf front edge, creating 1/2" setback from front edge.
4. Drill 5mm holes through marked circles.
5. Flip jig and align Right edge flush to wall, keeping Bottom edge flush to shelf front.
6. Drill remaining holes.

