


## **ASSEMBLY INSTRUCTION**






This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

Attach end caps (J) to under side panel (B), then attach under side panel (B) to upper side panel (A) using screws (I) and allen wrench (L) as shown.



Attach stretchers (C) and stretchers (D) to upper side panel (A) using screws (I) and allen wrench (L), then attach stretchers (D) and stretchers (E) to under side panel (B) using screw (I) and allen wrench (L) as shown.



Stretchers (D)'s gaps should Face downward.


3

Repeat step 2 to attach stretchers (C), stretchers (D) and stretchers (E) as shown. Using screws (I) and allen wrench (L).

Tighten all screws and carefully turn the assembled unit upright.

4

Put glass pad (K) onto all stretchers before putting on glass top (F), glass shelf (G) and glass bottom (H).



## Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.