



Assembly & Installation Instructions

CAUTION: Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation.

350029

WARNING - If any Special Control Devices are used with this Fixture, Follow the Instructions Carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a Qualified Electrical Contractor.


WARNING - This product contains chemicals known to the State of California to cause cancer, birth defects and /or other reproductive harm. Thoroughly wash hands after installing, handling, cleaning, or otherwise touching this product.


CAUTION - All glass is fragile, use care when handling Glass component(s) and or Lamp(s).

ASSEMBLY STEPS:



PASOS PARA ENSAMBLAR:

MODE D'ASSEMBLAGE:

1. D,E → A
2. R → D
3. B,A → C
4. F → S,H
5. S → T
6. F → G 
7. H,J → D
8. M,L → P
9. K → P
10. Q,N → U



**B, C, G & K
 (NOT FURNISHED)
 (NO INCLUIDA)
 (NON FOURNIE)**





Assembly & Installation Instructions

CAUTION: Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation.

350029

WARNING - If any Special Control Devices are used with this Fixture, Follow the Instructions Carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a Qualified Electrical Contractor.

WARNING - This product contains chemicals known to the State of California to cause cancer, birth defects and /or other reproductive harm. Thoroughly wash hands after installing, handling, cleaning, or otherwise touching this product.

CAUTION - All glass is fragile, use care when handling Glass component(s) and or Lamp(s).

ASSEMBLY STEPS:

PASOS PARA ENSAMBLAR:


MODE D'ASSEMBLAGE:

1. T,U → S
2. B,S → C
3. CC,DD,V → T (TO LOCK) (APRETAR) (À VERROUILLER)
4. DD → V
5. F → BB,Z
6. BB → AA
7. W → Z
8. Y,X → W
9. W → V
10. F → W,Y,X,V,T
11. F → G
12. X,Y → V
13. M,L → P
14. K → P
15. Q,N → R

ADJUST HEIGHT WITH "T"
 CC → S (TO LOCK)

AJUSTA LA ALTURA CON "T"
 CC → S (APRETAR)

RÉGLEZ LA HAUTEUR AVEC "T"
 CC → S (À VERROUILLER)



**B, C, G & K
 (NOT FURNISHED)
 (NO INCLUIDA)
 (NON FOURNIE)**

