




















ASSEMBLY INSTRUCTION

E198-12 72" ASYMMETRICAL DISPLAY BOOKCASE

A Left Upper Panel  1pc	B Right Upper Panel  1pc	C Left Under Panel  1pc	D Right Under Panel  1pc
E Horizontal Stretcher  8pcs	F Vertical Stretcher  8pcs	G Stretcher G  2pcs	H Stretcher H  2pcs
I Middle Stretcher  2pcs	J Small Wood Shelf  4pcs	K Large Wood Shelf  3pcs	L Bolt 1/4" x 1-3/4"  44pcs
M Screw 12mm  34pcs	N Screw (Anti-Tipping)  2pcs	O L Bracket (Anti-Tipping)  2pcs	P Wall Anchor (Anti-Tipping)  2pcs
Q Plastic Strap (Anti-Tipping)  2pcs	R Allen Wrench 1/4"  1pc		




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

***** Do not tighten screws & bolts until the entire unit is completely assembled.**

1


Attach Horizontal Stretcher (E), Stretcher H (H) and Stretcher G (G) to Left Upper Panel (A) and Right Upper Panel (B) by Bolt (L) and Allen Wrench (R) as shown.

*Please note the direction of stretcher.




2


Attach Vertical Stretcher (F) to Horizontal Stretcher (E), Stretcher H (H) and Stretcher G (G) by Bolt (L) and Allen Wrench (R) as shown.



- 3** Attach Left Under Panel (C), Right Under Panel (D) and Middle Stretcher (I) to Left Upper Panel (A) and Right Upper Panel (B) by Bolt (L) and Allen Wrench (R). Then, attach Horizontal Stretcher (E) to Left Under Panel (C) and Right Under Panel (D) by Bolt (L) and Allen Wrench (R) as shown.




- 4** Attach Vertical Stretcher (F) to Horizontal Stretcher (E) and Middle Stretcher (I) by Bolt (L) and Allen Wrench (R) as shown.




5

Attach Stretcher H (H) and Stretcher G (G) to Left Under Panel (C), Right Under Panel (D) and Vertical Stretcher (F) by Bolt (L) and Allen Wrench (R) as shown.


**6**

Attach Small Wood Shelf (J) to assembled metal rack by Screw (M) as shown.





7

Attach Large Wood Shelf (K) to assembled metal rack by Screw (M) as shown.




8

Select a location where you want the shelf mounted. Mark on the wall the two locations where the Wall Anchors (P) will be placed. Drill a hole for each anchor slightly smaller than the size of Screws (N). Push the Wall Anchors (P) as far as it will go with your finger. Tap gently with a hammer until the anchors are in. Then align the L Brackets (O) to the Wall Anchors (P) and insert Screws (N) to secure.



9

Insert each end of the Plastic Strap (Q) into L Brackets (O), then secure and tighten.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.