




BEST CHOICE
PRODUCTS



INSTRUCTION MANUAL

360° Rotating Jewelry Armoire
w/ Mirror and 4 Cubby Shelves

! NOTICE

Please retain these instructions for future reference.

- Firmly secure all bolts, screws, and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not fully tighten screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product is intended for residential use only.

TOOLS REQUIRED














1 PERSON
ASSEMBLY



UP TO 60 MIN.
ASSEMBLY


HARDWARE



PARTS

1


ARMOIRE



1 PC

2


SIDE PANEL I



1 PC

3


SIDE PANEL II



1 PC

4


TOP PANEL



1 PC

5


UPPER/LOWER SHELF



2 PCS

6


MIDDLE SHELF



1 PC

7


ARMOIRE SUPPORT



2 PCS

8


ROTATING PANEL



1 PC

9


CABINET BASE



1 PC

10


CABINET SIDE I



1 PC

11


CABINET SIDE II



1 PC






12

CABINET BACK



1 PC





PARTS



PRODUCT ASSEMBLY

1


Insert two **part A** cam bolts to the **part 6** middle shelf, then attach one **part 7** armoire support with two **part B** cam locks.



PRODUCT ASSEMBLY

2


Insert sixteen **part A** cam bolts to the **part 2 & 3** side panels, eight cam bolts per side panel.



3

Attach one **part 7** armoire supports with one **part B** cam lock and one **part C** dowel to the **part 3** side panel.



Attach two **part 5** upper/lower shelves and the **part 6** middle shelf with seven **part B** cam locks and seven **part C** dowels to the **part 3** side panel.



PRODUCT ASSEMBLY

4



Attach and secure the **part 2 side panel** to the other side of the shelves and supports with eight **part B cam locks** and eight **part C dowels**.




PRODUCT ASSEMBLY

5


Insert six **part B** cam bolt to the **part 4** top panel, then attach the top panel to side with **part 7** armoire support and **part 2 & 3** side panels with six **part B** cam locks and four **part C** dowels.



A x6



B x6




C x4

PRODUCT ASSEMBLY

6

Insert four **part B** cam bolts to the **part 8 rotating panel**, then flip the panel and insert another four **part B** cam bolts.




Attach the **part 8 rotating panel** to the other end of **part 2 & 3 side panels** with four **part B** cam bolts and four **part C** dowels.



PRODUCT ASSEMBLY

7



Attach the **part 1 armoire** to the two **part 7 armoire supports** with four **part E screws**, two screws per support.



PRODUCT ASSEMBLY

8

Turn the **part 8 rotating panel** and then secure the **part 1 armoire** with two **part E screws**.



PRODUCT ASSEMBLY






9

Locate the **part 10 & 11 cabinet sides** and attach the **part H cabinet runner set** with six **part F screws**, three screws per runner.

Flip the assembly where the **part 8 rotating panel** is facing up, then attach the **part 10 & 11 cabinet sides** with four **part B cam locks** and four **part C dowels**.



Attach the runner sets as shown with the runner wheel at the drawer compartment opening.






PRODUCT ASSEMBLY

10

Slide the **part 12 cabinet back** between the **part 10 & 11 cabinet sides**.




Attach the **part 9 cabinet base** to **part 10 & 11 cabinet sides** with four **part D screws**.



PRODUCT ASSEMBLY

11


Flip the armoire right side up and then attach six **part J knobs** to the **part 2 & 3 side panels** with six **part I screws**. Three knobs and three screws per side panel.



PRODUCT ASSEMBLY

12



Attach the **part 13 & 14 drawer sides** to the **part 15 drawer back** with four **part D screws**.
Insert the **part 16 drawer bottom**.



13

Insert four **part A cam locks** to the **part 17 drawer front**, then attach the **part J knob** to the drawer front with one **part 8 screw**.

Attach the drawer front to the drawer assembly with four **part B cam locks**.



PRODUCT ASSEMBLY

14





Flip the drawer assembly attach the **part G drawer runner set** to the drawer sides with six **part F screws**.

Slide the assembled drawer into its designated opening.

OPTIONAL: Use **part K stickers** to cover the any cam locks or screws as desired.



Attach the runner sets as shown with the runner wheels at the back of the drawer.





HELP CENTER



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660



WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.