


# ASSEMBLY INSTRUCTION


## SEASHELL SHAPED ACCENT CHAIR

**A** Under Leg Panel




1pc

**B** Upper Leg Panel




1pc

**C** Seat



1pc

**D** Bolt  
M6 x 30mm



1pc

**E** Bolt  
M6 x 45mm




4pcs

**F** Allen Wrench  
M6




1pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

**\*\*\* Do not tighten screws & bolts until the entire unit is completely assembled.**

**1** Attach Under Leg Panel (A) to Upper Leg Panel (B) by Bolt (D) and Allen Wrench (F) as shown.



**2** Attach assembled metal base to Seat (C) by Bolt (E) and Allen Wrench (F) as shown.



### Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.