

Rh Pearlised 38Cm Baking Tray

Please retain instructions for future reference.

CARE AND USE

Please retain instructions for future reference.

BEFORE FIRST USE Hand-wash thoroughly.

USING THE OVENWARE Suitable for domestic oven use only, up to but not exceeding 200 °C/Gas Mark 6.

Not suitable for use on a hob, in a microwave, under a grill, over a naked flame, on an open fire or barbecue.

Do not fill the ovenware more than two thirds of the capacity.

Use only heat-resistant plastic, silicone or wooden utensils; do not use metal ones.

Do not cut food in the ovenware, as this will damage the surface.

Do not overheat the ovenware or expose it to sudden temperature changes.

Never leave the ovenware unattended whilst in use and ensure that the kitchen is well-ventilated.

CLEANING THE OVENWARE Allow to cool thoroughly before moving or cleaning.

Do not pour cold water or liquid onto hot ovenware.

This ovenware is not dishwasher safe.

Clean the ovenware in warm, soapy water with a mild detergent and a soft cloth; do not use harsh or abrasive cleaners or scourers; rinse and dry thoroughly.

To remove stubborn stains, use a nonabrasive plastic mesh or pad with warm, soapy water.

Do not leave the ovenware to soak in water for long periods of time.

STORAGE Do not store wet ovenware; store in a dry, clean place.

If stacking the ovenware, place a layer of paper in-between to avoid scratching or damage.

CAUTION Always use heat-resistant oven gloves when handling hot ovenware.

Be cautious when moving ovenware in and out of the oven.

Discontinue use if the ovenware becomes chipped or damaged.

To be eligible for the extended guarantee, please retain your proof of purchase.

Made in China

Manufactured by: UP Global Sourcing UK Ltd, Victoria Street, Oldham, Manchester OL9 0DD. UK
Ultimate Products Europe Ltd, 19 Baggot Street Lower, Dublin, D02 X658. ROI