

BW14520B

Progress Mellow 24Cm Stockpot Blue

Please retain instructions for future reference.

CARE AND USE

Not suitable for deep fat frying.

Please retain instructions for future reference.

BEFORE FIRST USE Hand-wash thoroughly.

Suitable for use on hobs only, including induction.

For optimum energy efficiency, place the cookware on hob rings equivalent to the base size.

Do not let flames overlap the sides or handles.

To increase the longevity of the cookware, it is recommended to use silicone, wooden or nylon utensils.

Do not use metal utensils.

Do not overheat the cookware or allow to boil dry.

Never leave unattended whilst in use.

The non-stick coating is prone to discolouration.

This has no effect on the functionality of the cookware.

To avoid damage to ceramic hobs, always lift the cookware rather than drag it across the hob surface.

Screws may loosen over time; using a screwdriver, carefully retighten them.

Always allow to cool before cleaning.

This cookware is not dishwasher safe.

Hand-wash using a mild detergent and nonabrasive sponge, rinse and dry thoroughly.

Do not store wet cookware.

Always use heat-resistant oven gloves to move the cookware.

Never expose hot cookware to cold liquid.

If there is any evidence of damage to the cookware, dispose of it carefully.

Made in China

Manufactured by: UP Global Sourcing UK Ltd, Victoria Street, Oldham, Manchester OL9 0DD. UK

Ultimate Products Europe Ltd, 19 Baggot Street Lower, Dublin, D02 X658. ROI