




bestchoiceproducts



INSTRUCTION MANUAL

80-Inch Wooden
Chicken Coop



bestchoiceproducts

As shoppers, we're always trying to find the perfect balance between quality & value. At BCP, we believe we've achieved that. Our diverse catalog of everyday essentials is tailored especially to our customers & guaranteed to hit that sweet spot of high quality & low price.

— Always. —

! NOTICE

Please retain these instructions for future reference.

- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not firmly tighten the screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

TOOLS REQUIRED













2 PERSON
ASSEMBLY



APPROXIMATELY
30 MIN.
ASSEMBLY

HARDWARE



PARTS

1


FRONT



1 PC

2


BACK



1 PC

3


RIGHT SIDE



1 PC

4


LEFT SIDE



1 PC

5


SIDE FENCE



1 PC

6


FRONT FENCE



1 PC

7


BACK FENCE



1 PC

8


TRAY



1 PC

9


WINDOW FRAME



2 PCS

10


MIDDLE SUPPORT



2 PCS

11


ROOF FRAME



1 PC

12

LONG ROOF FRAME




1 PC

PARTS

13


RAMP



1 PC

14


ROOF



1 PC

15


LONG ROOF



1 PC

16


LEFT BOX SIDE



1 PC

17


RIGHT BOX SIDE



1 PC

18


BOX FLOOR



1 PC

19


BOX FRONT



1 PC

20


DIVIDER



1 PC

21

BOX ROOF




1 PC

PRODUCT ASSEMBLY

1


Attach a part 9 window frame to part 4 left side with two part A screws.



2

Attach a part 9 window frame to part 3 right side with two part A screws.


Attach part 16 left box side and part 17 right box side with four part B screws.



PRODUCT ASSEMBLY


3

Attach part 1 front and part 2 back to part 4 left side with four part B screws.
Attach a part I latch to the front door with six part H screws.



4


Attach part 3 right side with six part B screws.



PRODUCT ASSEMBLY

5


Attach part 13 ramp with two part C screws.



6

Attach part 6 front fence with three part D screws.


Attach two part I latches to the fence door with twelve part H screws.



PRODUCT ASSEMBLY


7

Attach part 7 back fence with three part D screws.



8


Attach part 5 side fence with six part B screws.



PRODUCT ASSEMBLY


9

Attach part 15 long roof with eight part E screws.



10


Attach part 12 long roof frame with six part F screws.



PRODUCT ASSEMBLY


11

Place two part 11 middle supports into the coop.
Slide in the part 8 tray.



12


Attach part 19 box front with four part B screws.



PRODUCT ASSEMBLY


13

Place part 18 box floor into the nesting box.
Slide part 20 divider into the slot on the box floor.



14


Attach the part 21 box roof with four part C screws, two screws per hinge.



PRODUCT ASSEMBLY

15

Attach part 14 roof with eight part E screws.




PRODUCT ASSEMBLY

16

Attach part 11 roof frame with four part F screws.

Attach part J handle with the part G bolt set.



Earn points while you shop. Join today!

bestchoiceproducts **rewards**

Join | Earn | Redeem

Give your friends 15% off their first order! For each successful referral you'll receive 100 points.

bestchoiceproducts.com



HELP CENTER



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.



WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.