














TENNEY INDOOR OUTDOOR BAR CART

ASSEMBLY INSTRUCTIONS

FIRSTIME & CO.®
— AMERICAN DESIGNED —

PARTS		STEP 1	STEP 2
<p>A</p>  <p>1 PC</p>		<p>Attach legs (C) to top tub (B). Tighten screws 75%</p> 	<p>Attach bottom tub (A) to X on legs (C). Tighten screws 75%</p> 
<p>B</p>  <p>1 PC</p>			
<p>C</p>  <p>1 PC</p>	<p>D</p>  <p>2 PC</p>		
<p>E</p>  <p>1 PC</p>	<p>F</p>  <p>2 PC</p>		
<p>G</p>  <p>12 PC</p>	<p>H</p>  <p>1 PC</p>	<p>STEP 3 Rotate cart. Align handles (D) at top of the legs (C). Tighten screws 75%.</p> 	<p>STEP 4 Attach bar (E) between handles (D) using end knobs (F). Tighten all screws 100%</p> 
		<p>FULLY ASSEMBLED</p> 	

NOTE: DO NOT TIGHTEN SCREWS 100% UNTIL FULLY ASSEMBLED.

Knobs (F) are attached to the bar (E). Please remove before assembly.