




BEST CHOICE
PRODUCTS



INSTRUCTION MANUAL

Pretend Play 50in Lemonade
Stand with Canopy

⚠ WARNING
ADULT ASSEMBLY REQUIRED

⚠ WARNING
CHOKING HAZARD - Small parts.
Not for children under 3 years old.










ⓘ NOTICE | Please retain these instructions for future reference.

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not fully tighten screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Be aware that moving parts can injure, crush, and cut.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product is intended for residential use only.

TOOLS REQUIRED



HARDWARE & ACCESSORIES



PARTS

1

COUNTERTOP



1 PC

2


FRONT PANEL WITH
CHALKBOARD



1 PC

3


CART BOTTOM PANEL



1 PC

4


RIGHT SIDE PANEL



1 PC

5

LEFT SIDE PANEL



1 PC

6

FRONT TOP CORNER
BRACKET



1 PC

7

BACK BOTTOM CORNER
BRACKET



1 PC

8


FRONT BOTTOM CORNER
BRACKET



1 PC

9


RIGHT VERTICAL
SUPPORT POLE



1 PC

10


LEFT VERTICAL
SUPPORT POLE



1 PC

11


LONG CANOPY
SUPPORT ROD















3 PCS


12

SHORT CANOPY
SUPPORT ROD




2 PCS






PRODUCT ASSEMBLY


- 1** Attach part 6 front top corner bracket between part 5 left side panel and part 4 right side panel using two part F screws.




- 2** Place part 2 front panel with chalkboard into the slots on part 4, part 5, and part 6. Secure part 2 front panel with chalkboard in place by placing part 8 front bottom corner bracket on top. Secure part 8 front bottom corner bracket to part 4 and part 5 side panels with two part F screws.




- 3** | Attach four **part 16** axel brackets to **part 3** cart bottom panel with eight **part B** screws.




- 4** | Slide **part 3** cart bottom panel into **part 4**, **part 5** and **part 8**. Attach **part 7** back bottom corner bracket to **part 3** cart bottom panel and secure to **part 4** and **part 5** with two **part F** screws.




- 5** | Slide **part 24** vertical inner panel into **part 25** inner shelf. Place **part 24** and **part 25** inside structure and secure to **part 4**, **part 5** and **part 3** with six **part B** screws.





- 6** | Insert two **part 17** axel rods through four **part 16** axel brackets. Insert **part G** barrel nut into **part 17** axel rod and have the **part G** barrel nut facing up. Place **part 18** axel spacer on each end of **part 17** axel rod.



- 7** | Insert four **part H** socket barrel nuts into **part 15** wheels from the non-patterned side. Secure the four wheels to the two **part 17** axel rods with four **part C** screws.




- 8** | Flip **part 1** countertop to backside facing up. Attach four **part I** mounting blocks with four **part D** screws. Flip **part 1** countertop over and place on top of cart base. Attach **part 1** countertop with four **part E** screws through the four **part I** mounting blocks.




9 | Insert **part 9** right vertical support pole and **part 10** left vertical support pole into **part 1** countertop.

NOTE: Part 10 left vertical support pole will have pre-drilled holes to secure each **part 13** disk shelf.

Secure **part 9** to **part 4** right side panel with two **part A** screws. Secure **part 10** to **part 5** left side panel with two **part A** screws.



10 | Insert **part 21** cart handle between two **part 22** handle mounts and secure with two **part B** screws. Attach **part 22** handle mounts to **part 4** right side panel with four **part B** screws.




11

Place three **part 13** disk shelves onto **part 10** left vertical support pole.


NOTE: **Part 10** left vertical support pole will have pre-drilled holes to secure each **part 13** disk shelf.

Attach each **part 13** disk shelf onto **part 10** left vertical support pole with one **part A** screw, three screws total.




12


Insert two **part 12** short canopy support rods and one **part 11** long canopy support rod onto **part 9** and **part 10** vertical support poles. Secure each **part 12** onto **part 9** or **part 10** with one **part A** screw. Secure **part 11** onto **part 9** and **part 10** with two **part B** screws.



- 13** | Insert two **part 11** long canopy support rods into **part 23** canopy. Place **part 23** canopy with **part 11** long canopy support poles onto **part 9**, **part 10** and **part 12** and secure in place with four **part B** screws.



- 14** | Hang **part 20** sign onto the **part 12** short support rod. Place **part 19** lemons and **part 14** cups as desired.





HELP CENTER

Question about your product? We're here to help. Visit us at:

bestchoiceproducts.com/pages/help



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660

WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.