

ASSEMBLY INSTRUCTION

5106BK 3PC COUNTER HEIGHT DINING SET, FAUX MARBLE TOP, METAL, 3A






This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual conponents to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

COUNTER HEIGHT CHAIR




Align the Chair Frame L&R(A) to the Seat Rail L&R(B) and Cross Bar L&R(C), insert the Bolt(I) to the holes, turn the L-Allen Key(L) to tighten them.



2

Attach the Seat Cushion(D) to the seat, insert the Screw(J) then tighten it.




Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratchresistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

COUNTER HEIGHT TABLE




Align the Table Leg Frame L&R(E) to Bottom Cross Bar(F) and Table Rail L&R(G) and tighten with Bolts(I). Turn the L-Allen Key(L) to tighten them.



2

Place the Table Top(H) on the smooth and the stable carpeted or padded surface. Tighten attached table frame to table top with Screws(K).



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratchresistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.