


INSTRUCTION MANUAL


Shag Fur Donut Cuddler

MAIN DIAGRAM



REMOVING CUSHIONS

- Unzip middle zipper and remove the round cushion.
- Unzip side zipper and remove the long cushion.



WASHING INSTRUCTIONS

- · Remove the cushions from the cover.
- · Wash cover in a washing machine on the following settings:
 - Cold temperature
 - Delicate cycle
- Do not wring or twist.
- Do not bleach.
- Do not iron or dry clean.
- Cushions are handwash only.

DRYING INSTRUCTIONS

- To maintain fur softness, dry cover immediately after washing.
- Do not air dry.
- Dry in a dryer on the following settings:
 - Tumble dry at low temperature
 - Delicate cycle



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com











Chat Support

Product Inquiry

Orders FA

Product Assembly

Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

△WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.