




bestchoiceproducts



INSTRUCTION MANUAL

2-Story Rabbit Hutch

NOTICE

Please retain these instructions for future reference.

- Be aware that extra hardware may be included.
- Do not stand on or use any part of this product as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

TOOLS REQUIRED



PHILLIPS
SCREWDRIVER



SMALL
WRENCH



30 LBS
CAPACITY












1 PERSON
ASSEMBLY






APPROXIMATELY
45 MIN.
ASSEMBLY

HARDWARE

1 M3.5 x 45mm SCREW  8 PCS	2 M3 x 30mm SCREW  8 PCS	3 M3 x 12mm SCREW  2 PCS	4 M3 x 16mm SCREW  28 PCS	5 M4 x 22mm BOLT SET  2 PCS
6 RAMP SUPPORT  1 PC	7 LATCH  4 SETS	8 PLATE  1 PC	9 ARM  1 PC	


PARTS

A UPPER CAGE  1 PC	B LOWER CAGE  1 PC	C LEFT SIDE  1 PC
--	--	--

PARTS

D


RIGHT SIDE



1 PC

E


DIVIDER



1 PC

F


FLOOR SUPPORT



2 PCS

G


LOWER BACK



1 PC

H


UPPER BACK



1 PC

I


UPPER TRAY



1 PC

J


LOWER TRAY



1 PC

K


ROOF



1 PC

L

RAMP




1 PC

PRODUCT ASSEMBLY


1

Attach four part 7 latch sets to the part A upper cage and part B lower cage with sixteen part 4 screws.



2


Attach part 6 ramp support to the part G lower back with two part 5 bolt sets.



PRODUCT ASSEMBLY


3

Place the part A upper cage on top of the part B lower cage, then attach the part C left side and part D right side with eight part 1 screws.



4


Attach part G lower back and part H upper back with eight part 2 screws.



PRODUCT ASSEMBLY

5


Place two part F floor supports in the designated slots inside the hutch.



6

Place the part L ramp on the floor support and ramp support, then secure it with two part 4 screws.


Slide in the part E divider.



7

Attach part 8 plate to the back with two part 3 screws.


Attach part K roof with six part 4 screws.



PRODUCT ASSEMBLY

8

Lift the roof and attach the part 9 arm with four part 4 screws.
Slide in the part I upper tray and part J lower tray.





HELP CENTER



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.



WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.