



Thank you for purchasing Leick Furniture products.
Contact customer service for comments or concerns.

Sheboygan, WI






920-451-4060

info@leickhome.com








www.leickhome.com

Assembly Instructions, #9069 Gold Metal and Wood Side Table with Top AC / USB Charging

Parts List

Item	Parts	Description	Quantity
A		Top Assembly	1
B		Left Leg Frame	1
C		Right Leg Frame	1
D		Shelf	1
E		Metal Rail	1


Hardware List

Item	Hardware	Description	Quantity
1		Long Allen Bolts	4
2		Short Allen Bolts	10
3		Flat Washers	14
4		Lock Washers	14
5		Allen Wrench	1
6		Drawer Pull	1
7		Machine Screw	1

Assembly Steps


Step 1

- 1.1** Place the top assembly (A) to the left leg frame (B) with its wire hole facing along side of leg frame with 2 inserts on top part as shown on the following sketch.
- 1.2** Insert the shelf (D) and metal rail (E) onto the left leg frame.



Step 2


- 2.1** Fasten the parts in **Step 1** with 2 long bolts and 5 short bolts. Do not tighten.
- 2.2** Tighten two long bolts first, and push parts down to the metal leg frame while tightening the short bolts.



Assembly Steps


Step 3

3.1 Insert the right leg frame (C).



Step 4

4.1 Do the same thing as per **Step 2** to tighten the bolts.



Step 5

5.1 Place the table upright.

5.2 Adjust the levelers on the bottom of legs if needed.

5.3 Open the drawer to screw the drawer pull.

