

Salter Marblestone 24cm Round Pan

BW02777G3EU7

Please retain instructions for future reference.

Care and use

Before first use, it is essential to hand-wash the ovenware thoroughly. This product is designed for use in a domestic oven only, with a maximum temperature of 220 °C (Gas Mark 7), and is not suitable for use on a hob, in a microwave, under a grill, over an open flame, or on a barbecue. To prevent damage, do not overheat the ovenware or expose it to sudden temperature changes. Only use heat-resistant plastic, silicone, or wooden utensils, avoiding metal ones, and refrain from cutting food directly in the ovenware, as this can harm the surface. Always supervise the ovenware during use and ensure your kitchen is well-ventilated. If the ovenware becomes chipped or damaged, please discontinue use. Allow the ovenware to cool completely before moving or cleaning. While it is safe for dishwasher use, hand-washing is recommended to best protect and preserve it. Clean the ovenware using warm, soapy water with a mild detergent and a soft cloth, and avoid harsh or abrasive cleaners or scourers. Rinse and dry thoroughly, and for stubborn stains, use a non-abrasive plastic mesh or pad with warm, soapy water. Do not leave the ovenware to soak for extended periods, and ensure it is stored in a clean, dry place, avoiding storage when wet. Always use heat-resistant oven gloves when handling hot ovenware, exercise caution when moving it in and out of the oven, and discontinue use if the ovenware becomes damaged or defective. Additionally, do not pour cold water or liquid onto hot ovenware.

Made in **China**.

Manufactured by: UP Global Sourcing UK Ltd, Address: Victoria Street, Oldham, Manchester OL9 0DD. **UK**.

Ultimate Products Europe Ltd, Address: 19 Baggot Street Lower, Dublin, D02 X658. **ROI**.