

Step 3


HEKMAN

ASSEMBLY INSTRUCTIONS

23324 - Arm Chair







Step 1: Assemble the back frame and the chair seat together with Bolt (E, F), Washer (C) and Lock washer (D) using Wrench (A).

Step 2: Assemble the front legs to the chair with Nut (B), Washer (C) and Lock washer (D) using Wrench (A). Attach the arm to back legs with screw (G). Do not tighten screw or nuts completely

Step 3: Set the chair upright on a flat surface. Adjust front legs so all four chair legs touch the floor, tighten nut completely on front legs. (The seat cushion may need to be loosen to adjust front legs).

Step 4: Tighten screw that attached arms to back legs.



Step 2