

ASSEMBLY INSTRUCTIONS




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


Attach Seat (B) to Back Leg Frame (A) using Bolt (G & I), Spring Washer (J & L) and Flat Washer (K & M) with Allen Wrench (N). Do not fully tighten the bolts in this step.



Attach Front Leg (C & D) to Seat (B) using Bolt (H), Spring Washer (J) and Flat Washer (K) with Allen Wrench (N). Half tighten all the bolts in this step.



Attach Side Stretcher (E & F) to Front Leg (C & D) and Back Leg Frame (A) using Screw (O) with Screwdriver (Not Provided). Fully tighten all the bolts and screws in this step.



Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.