




















LIAM SWIVEL BAR STOOL

ASSEMBLY INSTRUCTIONS

FIRSTIME & CO.®
— AMERICAN DESIGNED —

PARTS		STEP 1	STEP 2	STEP 3
A  1 PC	B  1 PC	Attach chair back (A) to seat frame (B). Tighten screws 75%. 	Attach swivel plate (F) to seat frame (B). Tighten screws 75%. 	Attach bottom frame (D) to legs (E). Attach legs (E) to middle frame (C). Tighten screws 75%. 
C  1 PC	D  1 PC			
E  4 PC	F  1 PC			
G  1 PC	H  (1") 2 PC			
I  (5/8") 23 PC	J  4 PC	STEP 4 Attach swivel plate (F) to middle frame (C). Tighten all screws 100%. 	STEP 5 Attach cushion (G) to the seat frame (B). 	FULLY ASSEMBLED 
K  2 PC	L  1 PC			
 PHILIPS HEAD SCREWDRIVER (NOT INCLUDED)				

NOTE: PHILIPS HEAD SCREW DRIVER REQUIRED FOR ASSEMBLY (NOT INCLUDED)
DO NOT TIGHTEN SCREWS 100% UNTIL FULLY ASSEMBLED.