




ITEM NAME/NOM D'ITEM: SHORELINE ACCENT CHAIR
ITEM #/NO. ITEM: 704042

PARTS LIST/LISTE DES PIÈCES


(1)	(2)
 ×1	 ×1

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE

I



II



Please use the attached adjustable footglides to level the chair on an uneven surface.