

Salter Marblestone 27cm Loaf Pan

BW02776G3EU71

Please retain instructions for future reference.

Care and use

Before first use, it is essential to hand-wash the ovenware thoroughly. This product is designed for domestic oven use only, with a maximum temperature of 220 °C or Gas Mark 7. Please refrain from using it on a hob, in a microwave, under a grill, over an open flame, or on a barbecue. To prevent food from sticking, lightly coat the inner surface with oil or butter, and do not fill it more than two-thirds of its capacity. Only use heat-resistant plastic, silicone, or wooden utensils, avoiding metal ones to protect the surface. Cutting food in the ovenware is not advisable as it may cause damage. Additionally, do not subject the ovenware to overheating or sudden temperature changes, and never leave it unattended while in use; ensure that the kitchen is well-ventilated. After use, allow the ovenware to cool completely before moving or cleaning, and avoid pouring cold water or liquid onto it while it is hot. Please note that this ovenware is not dishwasher safe; instead, clean it with warm, soapy water and a mild detergent using a soft cloth, avoiding harsh or abrasive cleaners and scourers. For stubborn stains, a non-abrasive plastic mesh or pad with warm, soapy water is recommended. Ensure that the ovenware does not soak in water for extended periods. When storing, do not keep it wet and place it in a clean, dry area. If stacking, use paper in between layers to prevent scratching or damage. It is crucial to always use heat-resistant oven gloves when handling hot ovenware and to exercise caution when moving it in and out of the oven. Should the ovenware become damaged or defective, discontinue its use immediately.

Made in **China**.

Manufactured by: UP Global Sourcing UK Ltd, Address: Victoria Street, Oldham, Manchester OL9 0DD. **UK**.

Ultimate Products Europe Ltd, Address: 19 Baggot Street Lower, Dublin, D02 X658. **ROI**.