



BEST CHOICE
PRODUCTS



INSTRUCTION MANUAL

Ceramic Christmas Tree Night Light

! NOTICE | Please retain these instructions for future reference.

- This product is not intended for outdoor use.
- This product is seasonal and not intended for permanent installation or use.
- Unplug the product when not in use or when unattended.
- Do not leave children unattended with this night light. This product is NOT a toy.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product is intended for residential use only.

! WARNING

- Do not mount or place near sources of heat such as fireplaces, candles, or heaters.
- Do not cover this product with cloth, paper or other materials when in use.
- To reduce the risk of electric shock, this product uses a polarized plug (one prong wider than the other) and will only fit into a polarized outlet. If plug does not fit in polarized outlet, flip plug and try again. If it still does not fit, contact an electrician. Do not attempt to use this product if the plug does not fit. Do not alter or replace plug.
- Do not leave the night light on for an extended period of time to prevent any potential hazards

PARTS


A CERAMIC CHRISMAS TREE NIGHT LIGHT  1 PC	B STAR TOPPER  2 PCS	C LIGHT BULB (PRE-ATTACHED)  1 PC
---	--	---

TO USE

- Before plugging in the night light, carefully inspect it for any visible damage.
- Select a suitable electrical outlet and ensure it is easily accessible.
- Make sure the outlet is not overloaded with other devices.
- Firmly insert the night light plug into the outlet.
- Confirm that the plug is fully inserted to ensure a secure connection.
- Rotate the plug to your preferred orientation, if applicable.
- Locate the switch/button on the ceramic night light and move it to the "ON" position to illuminate the bulbs.
- To turn the light off, move the switch/button to the "OFF" position.

REPLACING BULB

- If the bulb needs to be replaced, twist the plug assembly to the left (counterclockwise) and carefully pull it straight down to remove it from the ceramic tree night light.
- The plug assembly uses a 7-watt, candelabra-base, UL-listed bulb.
- Replace the bulb with a new 7-watt candelabra-base bulb.
- Reinsert the plug assembly into the ceramic night light and twist to the right (clockwise) until securely in place.





HELP CENTER

Question about your product? We're here to help. Visit us at:

bestchoiceproducts.com/pages/help



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660

WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.