

# ONE COLL. TEAK ROOT CONSOLE TABLE

## OWNER'S MANUAL


VENDOR ITEM NO. : JVHS23B / JVHS23T



### ASSEMBLY PARTS LIST

BOX # 1				HARDWARE KIT PACKED IN BOX # 1			
				SKU : JVZZOCTGRP			
PART NO.	IMAGE	DESCRIPTION	QUANTITY	PART NO.	IMAGE	DESCRIPTION	QUANTITY
JVHS23B		BASE	1	JVZZOCTGRP		Glass Top Rubber Pad (1 cm Dia.)	4
BOX # 2				FULLY ASSEMBLED			
PART NO.	IMAGE	DESCRIPTION	QUANTITY				
JVHS23T		GLASS TOP	1				

### ASSEMBLY INSTRUCTIONS



**1**

**2**

**3**

**ASSEMBLY COMPLETE**

### REPLACEABLE PARTS LIST

PART NO.	IMAGE	DESCRIPTION
JVZZOCTGRP		GLASS TOP RUBBER PAD
JVZZOCLVR		BASE LEG LEVELER

# ONE COLL. TEAK ROOT CONSOLE TABLE

## OWNER'S MANUAL

VENDOR ITEM NO. : JVHS23B / JVHS23T



### **WARNING :**

- Maximum distributed load capacity : 225 lbs
- Sitting, standing or jumping on this product may result in damage or injury

### **ROUTINE MAINTENANCE :**

If uneven, your furniture can be leveled by adjusting the levelers under the base

### **CARE AND CLEANING : WOOD FURNITURE**

**WOOD :** Dust frequently with a clean, damp, lint-free cloth. Frequent dusting will remove abrasive build-up which can damage a finish over time. Avoid using oily polishes or waxes. Avoid exposing your furniture to strong sunlight. Prolonged exposure to direct sunlight can fade the finish of your furniture. Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Do not place hot items on top of surface, always use a mat or other protector. Alcohol, nail polish and perfume are also dangerous, as they can dissolve the furniture finish on contact and may require professional repairs.

**GLASS :** Clean with a slightly damp cloth and dry immediately with a lint-free cloth. Use only mild detergents and cleaning solutions which are recommended for cleaning glass. Use coasters and placemats on glass table tops to prevent marking on the surface of your product.