




ITEM NAME/NOM D'ITEM: LYCHEE CHAISE LOUNGE
ITEM# /NO. ITEM: 704237


PARTS LIST/LISTE DES PIÈCES

(1)	(2)
 x1	 x 2
(3)	(4)
 x1	A.  x 8 M6x35 B.  x 8 Ø7x13x1 C.  x 1


ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE

Do not FULLY TIGHTEN the screws or nuts for any step until all are in place.


I



II



III



Please use the attached adjustable footglides
to level the lounge on an uneven surface.