BEST CHOICE PRODUCTS

3 Pc Lighted Christmas Bow Set

INDOOR/OUTDOOR USE
(IP44 Water Resistant)

LED LIGHTS WITH 8 LIGHTING FUNCTIONS:

1. Combination
2. In Wave
3. Sequential
4. Slow Glow
5. Chasing/Flash
6. Slow Fade
7. Twinkle/Flash
8. Steady On

INCLUDES TIMER WITH MEMORY FUNCTION (ON 6 HOURS / OFF 18 HOURS)

ON 6HRS	(e.g. 4PM - 10PM)
OFF 18HRS	(e.g. 10PM - 4PM)

Questions about your product? Visit our help center via the QR code or link below and search for your product.
bestchoiceproducts.com/pages/help

3 Pc Lighted Christmas Bow Set

Requires 3 AA batteries each (not included)

BATTERY BOX OPERATION

1. Press the button to turn the lights **ON.**
2. Continue pressing the button to cycle through the lighting functions, stop when you've reached your desired function.
3. Press the button again to turn the lights **OFF.**

NOTE: To turn off the lights, you have to click through all the lighting functions.

MOUNTING

1. Use the back loop to hang the bow on any adhesive/suction cup hooks, nails, trees, garlands or wreaths **(not included).**
2. Mount outside or inside the home to celebrate the holidays.

Questions about your product? Visit our help center via the QR code or link below and search for your product.
bestchoiceproducts.com/pages/help