



bestchoiceproducts



INSTRUCTION MANUAL

5-in-1 Outdoor
Sport & Center

! NOTICE

Please retain these instructions for future reference.

- Please read all instructions before attempting to install or assemble this item. Assembly should be done by adults only.
- Firmly secure all screws before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Product is intended for outdoor use.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

! WARNING

- Do not hang from the rim or climb on the pole. Do not climb on the base or structure in general, as this could result in serious injuries.
- Do not overtighten the hardware as this may damage the products structure.
- Adjustment and moving of the basketball set must be carried out by adults.
- The set requires two people for assembly.

TOOLS REQUIRED



WRENCH
(2, PROVIDED)



INTENDED
FOR AGES 8+



2 PERSON
ASSEMBLY



UP TO 45 MIN.
ASSEMBLY

HARDWARE

1

CONNECTOR
KNOB



1 PC

2

8 x 50mm
BOLT &
WASHER SET



8 PCS

3

8 x 30mm
BOLT &
WASHER SET



4 PCS

4


8 x 15mm
BOLT &
WASHER SET



2 PCS

5

NET BUNGIE



28 PCS


6

NET ROPE



2 PCS

PARTS



PRODUCT ASSEMBLY

1


Connect the part A right rear support to the part C right corner, then repeat to connect the part B left rear support to the part D left corner.

2

Connect the two corner assemblies with the part N large net bottom support.

3

Locate and connect parts F & G upper corner supports, then attach the upper corners to the part A & B rear supports.



PRODUCT ASSEMBLY



4

Use the part 6 net rope to attach the part R large soccer net to the assembled net frame (see steps 1-3).

Begin by draping the net over the frame to reach the optimum shape, then thread the rope through the net and around either the part A or B corners.

Tie a knot and then continue threading the rope around the frame and through the net, then tie a second knot to secure the net to the frame.


Set this assembly aside.



5

Locate and attach the part I small net top support to the part J & K side supports.

Attach the part M small net support to the small net assembly.



PRODUCT ASSEMBLY

6

Use the part 5 net bungies to attach one part S small net to the small net frame assembly.

NOTE: There are two nets in this set, use the net with built-in hoops for best results.


Begin by draping the net over the frame to reach the optimum shape, then take on bungee, loop the cord around the frame and thread through the net.

Insert the end of the bungee back into bungee's knot and pull until taught.

Repeat with the remaining bungies until the net is completely secured. Set this assembly aside.

7

Insert two part H connector rods into the part F & G upper corners, then attach the assembled small net. Connect the part M & N bottom supports as indicated.



PRODUCT ASSEMBLY

8


Locate the part O basketball pole and attach the part P backboard & part Q basketball hoop with four part 2 bolt & washer sets.

Secure the part O basketball pole to the part P backboard by attaching two part E bracing rods with two part 4 bolt & washer sets and one part 4 bolt set.

9

Insert the part O basketball pole into the opening on the part I small net top support and secure with one part 1 connector knob.

Secure the basketball pole to the net top support by attaching two part L lower bracing rods with two part 2 bolt & washer sets and one part 3 bolt and washer set.





HELP CENTER



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.



WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.