









# ASSEMBLY INSTRUCTION

## 1-DRAWER WRITING DESK


<b>A</b>	Top Frame	<b>B</b>	Cylinder Foot	<b>C</b>	Short Foot Joint	<b>D</b>	Bun Foot
							
1 PC		4 PCS		2 PCS		4 PCS	
<b>E</b>	Long Foot Joint	<b>F</b>	Wood Dowel ø8*30mm	<b>G</b>	Screw ø4*40mm		
							
1 PC		4 PCS		2 PCS			




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

**1**

Attach Cylinder Foot (B) to Top Frame (A) and rotate clockwise.


**2**

Attach Long Foot Joint (E) to Short Foot Joint (C) using Wood Dowel (F) with Screw (G).



**3**

Attach Short Foot Joint (C) to Cylinder Foot (B) using the Bun Foot (D) and rotate clockwise.



### Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.